



DRAFT

ESIE03-01B



Service Manual

PCO² Controller for Large Chillers

For M series

Software version V2.5M6

PART 1 FUNCTIONAL DESCRIPTION 1

| | |
|---|----------|
| 1 Functional Control | 2 |
| 1.1 What Is in This Chapter | 2 |
| 1.2 Digital output | 3 |
| 1.3 Thermostatic control..... | 4 |
| 1.4 Setting of MOW | 6 |
| 1.5 Freeze-up control..... | 7 |
| 1.6 Lead-lag Control..... | 9 |
| 1.7 Capacity Limitation | 10 |
| 1.8 Pump Control | 11 |
| 1.9 Floating setpoint..... | 13 |
| 1.10 Fan management..... | 14 |
| 1.11 EEV driver..... | 16 |
| 1.11.1 Applicable units | 16 |
| 1.11.2 Basic unit setup..... | 16 |
| 1.11.3 Applicable Parts | 17 |
| 1.11.4 Applicable software | 17 |
| 1.11.5 Related Software menus..... | 17 |
| 1.11.6 Related LEDs | 18 |
| 1.11.7 Overview alarms | 18 |
| 1.11.8 Reset procedures for EEV NOT CLOSED alarm..... | 19 |
| 1.11.9 Remarks | 19 |
| 1.11.10 Check wiring..... | 19 |
| 1.12 Network hardware overview..... | 20 |
| 1.12.1 Unit setup..... | 20 |
| 1.12.2 External connections setup..... | 20 |
| 1.13 DICN (network) Overview | 22 |
| 1.13.1 On/Off management | 23 |
| 1.13.2 Changeable DI management | 24 |
| 1.13.3 Cooling heating Management | 24 |
| 1.13.4 schedule timer Management..... | 24 |
| 1.13.5 Limitation management | 25 |
| 1.13.6 Free cooling..... | 25 |
| 1.13.7 Dual setpoint Management..... | 25 |
| 1.13.8 Manual Management..... | 26 |
| 1.13.9 Automatic thermostat management..... | 26 |
| 1.13.10 External thermostat Management | 26 |
| 1.13.11 Pump management | 26 |
| 1.13.12 Pumpdown | 26 |
| 1.13.13 Priority Management..... | 27 |
| 1.13.14 Changeable analogue input management | 28 |
| 1.14 Free cooling..... | 29 |
| 1.14.1 Free cooling on ambient temperature | 29 |
| 1.14.2 Free cooling on difference between entering water evaporator and ambient temperature..... | 31 |
| 1.15 Changeable analogue input..... | 32 |

| | | |
|---------------|--|-----------|
| 2 | The digital Controller for the Large Chillers | 33 |
| 2.1 | What Is in This Chapter..... | 33 |
| 2.2 | The Controller..... | 34 |
| 2.2.1 | Version of software..... | 35 |
| 2.2.2 | Range of application..... | 36 |
| 2.2.3 | General features of the medium and large controller..... | 37 |
| 2.2.4 | Procedure : software upload/download..... | 38 |
| 2.3 | Start/Stop, Cool/Heat and Temperature Setting..... | 39 |
| 2.4 | What Happens in Case of an Alarm or a Warning | 40 |
| 2.5 | Menu Overview | 41 |
| 2.6 | How to Read or Adjust Parameter Settings: the Programming Procedure..... | 42 |
| 2.7 | Read-out Menu..... | 43 |
| 2.8 | Set Points Menu..... | 46 |
| 2.9 | User Settings & ServiceMenu..... | 48 |
| 2.9.1 | User Settings Menu..... | 48 |
| 2.9.2 | Service Menu | 59 |
| 2.10 | Timers Menu..... | 67 |
| 2.11 | Safety & History Menu..... | 70 |
| 2.12 | Info Menu | 74 |
| 2.13 | Input/Output Status Menu..... | 76 |
| 2.14 | User password Menu..... | 81 |
| 2.15 | Cool/Heat Menu | 82 |
| 2.16 | Network Menu..... | 83 |
| 2.17 | To adjust the contrast of the display..... | 84 |
| 2.18 | To enter the pumpdown menu | 85 |
| | | |
| PART 2 | TROUBLE SHOOTING..... | 87 |
| | Overview of Fault Indications and Safeties..... | 87 |
| 1. | Unit and Circuit Errors | 89 |
| 2. | EEV Driver Error list..... | 91 |

Part 1 Functional Description

Introduction This part gives more detailed information on the functions and controls in the unit. This information is used as background information for troubleshooting. An extensive overview of the functioning of the controller is also given in this part. Prior knowledge of the controller is essential in detecting information for servicing and troubleshooting.

What is in this part? This part contains the following chapters:

| Topic | See page |
|---|----------|
| 1 – Functional Control | 2 |
| 2 – The Digital Controller for the Large Chillers | 33 |

1 Functional Control

1.1 What Is in This Chapter

Introduction This chapter will give more detailed information on the functions used to control the system. Understanding these functions is vital when diagnosing a malfunction, which is related to functional control.

Overview This chapter covers the following topics:

| Topic | See page |
|----------------------------------|----------|
| 1.2 – Digital output | 3 |
| 1.3 – Thermostatic Control | 4 |
| 1.5 – Setting of MOW | 6 |
| 1.5 – Freeze-up Control | 7 |
| 1.6 - Lead-lag Control | 9 |
| 1.7 - Capacity Limitation | 10 |
| 1.8 - Pump Control | 11 |
| 1.9 - Floating setpoint | 13 |
| 1.10 – Fan management | 14 |
| 1.11 – EEV driver | 16 |
| 1.12 – Network hardware overview | 20 |
| 1.13 – DICN network | 22 |
| 1.14 – Free cooling | 29 |
| 1.15 – Changeable analogue input | 32 |

1.2 Digital output

The following table shows the different types and their digital outputs, the digital outputs can be selected in the service menu:

| WW / AW | DO1 | DO2 | 100% capacity | 2 nd Evap pump | Evap. Heatertape | Gen. Operation | Free cooling | Condenser Pump | REV. Valve(C/H) |
|---------|-----|-----|---------------|---------------------------|------------------|----------------|--------------|----------------|-----------------|
| CO | / | x | x | x | x | X | x | / | / |
| HO | x | x | x | x | x | X | x | x | x |
| HR | x | x | x | x | x | X | x | x | x |
| HP | x | x | x | x | / | X | / | x | x |
| RC | x | x | x | x | x | X | x | / | / |
| CA | x | x | x | x | x | X | / | / | / |

WW: Water water cooled
AW: Air water cooled

HO: Heating only
CO: cooling only
HP: Heatpump
HR: Heat recovery
RC: Remote condenser
CA: ER

Overview of the possible functions

100% CAPACITY: switches a contact when unit has reached 100%.

2nd EVAP. PUMP: this output handles the dual evaporator pump control.

- To switch from one pump to another after a number of working hours. In this situation the compressors are not switched off during switchover.
- This function is also used to switch from one pump to another in case of a flow error. In this situation the compressors are switched off during switchover.

EVAP. HEATERTAPE: this activates a function to protect the evaporator against freezing when the pump is switched off.

GEN. OPERATION: when this function is activated a contact closes when the system is on.

FREE COOLING: this activates the free cooling function. For more details on free cooling please refer to page 29.

CONDENSER PUMP:

- In cooling mode: the condenser pump contact will close on of the thermostat function.
- In other mode (heating/double thermostat): the condenser pump contact will close if the evaporator pump contact is closed.

REV. VALVE (C/H): this function allows to switch a reversing valve by closing a contact in heating mode and opening the contact in cooling or double thermostat mode.

1.3 Thermostatic control

Introduction The unit is equipped with a thermostat, which controls the cooling or heating capacity of the unit.

Three different types of control exist:

- ⋮ manual control mode or a control of the capacity by the operator
- ⋮ inlet water setpoint evaporator control mode or a control using the entering evaporator water temperature.
- ⋮ Outlet water setpoint evaporator control mode or a control using the leaving evaporator water temperature.

Manual mode versus automatic mode The following table shows the difference between manual and automatic mode:

| If... | then there is... |
|--|-------------------------------------|
| Manual capacity control (=fixed capacity step control) | No thermostat control. |
| Automatic control | An inlet/outlet thermostat control. |

Automatic control

The default value and the upper limit of the thermostat parameters are listed in the table below.

| INLET CONTROL | | Default value | Lower limit | Upper limit |
|----------------|-------|---------------|-------------|-------------|
| Steplength - a | (K) | 1.5 | 0.4 | 2.0 |
| Load-up time | (sec) | 180 | 15 | 300 |
| Load-down time | (sec) | 20 | 15 | 300 |
| Setpoint | (°C) | 12.0 | 7.0 | 23.0 |

| OUTLET CONTROL | | Default value | Lower limit | Upper limit |
|---------------------|-------|---------------|-------------|-------------|
| Steplength - a | (K) | 0.6 | 0.4 | 2.0 |
| Step difference - b | (K) | 0.2 | 0.2 | 0.8 |
| Load-up time | (sec) | 30 | 15 | 300 |
| Load-down time | (sec) | 15 | 15 | 300 |
| Setpoint | (°C) | 7.0 | 4.0 | 16.0 |

Inlet Evaporator control




Fig. Inlet evaporator control (Cooling)

In DICN the controller will calculate how many steps are necessary and will then decide (on priority settings) whether the unit will raise the steps in a short time (15s between loadup/down) or divide the steps among the slave units.

Outlet evaporator control




Fig. Outlet evaporator control (Cooling)

Controller Screen 3 of the user setting menu provides the ability to modify the thermostat parameters

| Line n° | Display | Description | Lower limit | Upper limit | Step | Default |
|---------|-------------------|----------------------|-------------|-------------|------|---------|
| 1 | THERMOST.SETTINGS | screen title | | | | |
| 2 | STEPLENGTH | Step length (°C) | 0.4 | 2.0 | 0.1 | 1.5 |
| 3 | STEPPDIFFERENCE | Step difference (°C) | 0.2 | 0.8 | 0.1 | 0.6 |
| 4a | LOADUP | Load up time (s) | 15 | 300 | 1 | 180 |
| 4b | LOADDOWN | Load down (s) | 15 | 300 | 1 | 20 |

1.4 Setting of MOW

It will be possible to change the MOW in the service menu. Thus the installer can change the MOW if necessary (e.g. in case of a glycol treated unit this means no extra option is needed because the installer can adjust the MOW himself).

General overview

The following table shows a general view of freeze-up temperatures in case of protection and prevention.

| | Minimum outlet water (M.O.W.) | FP set (Freeze-up protection) | FP Solution | Glycol percentage |
|----------|-------------------------------|---------------------------------|-------------|-------------------|
| Standard | 4°C | 2.5°C | 0°C | 0% |
| ZH | -5°C | -6.5°C | -16°C | 30% |
| ZL | -10°C | -11.5°C | -22°C | 40% |

With FP Set: DDC-software of the freezing point equal to M.O.W.

With FP Solution: actual freeze-point value of the water glycol solution.

1.5 Freeze-up control

Introduction Freeze-up control is used to protect the evaporator against accidentally freezing. Depending on the unit range there are two kinds of freeze-up controls.

- The freeze up prevention will reduce the capacity step of the circuit to avoid freeze-up of the evaporator.
- The freeze-up protection will stop the compressor to avoid possible freeze-up of the evaporator.

These functions are available on all large chillers.

Freeze up prevention

| Characteristics | Freeze up prevention |
|-----------------|--------------------------------------|
| Control device | Sensor |
| Diagram name | R3T, R4T |
| Activation | Outlet water temperature < M.O.W.-1K |
| Result | Loaddown of 1 thermostat step |
| Reset | Outlet water temperature > M.O.W. |
| Result | Normal mode |

Freeze up protection

| Characteristics | Freeze up protection |
|-----------------|---|
| Control device | Sensor |
| Diagram name | R3T, R4T |
| Activation | Outlet water temperature < M.O.W.-1.5K (= 2.5°C for standard unit) |
| Result | unit disabled + register inlet water temperature |
| Reset | Manual reset if inlet temperature is raised with 1.5K (= 1 thermostat step) ⁽¹⁾ |
| Result | unit enabled |

(1) Alarm is held and must be reset manually. It can only be reset when the temperature rises with 1 thermostat step.

The following table shows a general view of freeze-up temperatures in case of protection and prevention

| | Minimum outlet water (M.O.W.) | Freeze-up protection | Freeze-up prevention |
|-----------------|-------------------------------|----------------------|----------------------|
| Standard | 4°C | 2.5°C | 3°C |
| | 2°C | 0.5°C | 1°C |
| | 0°C | -1.5°C | -1°C |
| ZH | -5°C | -6.5°C | -6°C |
| ZL | -10°C | -11.5°C | -11°C |


Freeze-up control

It is possible to disable the freeze-up alarm when the unit is switched off. This can be done in the service menu.

| Line N° | Display | Setting | Description | Explanation |
|---------|-----------|----------------------|--------------------|---|
| 1 | FREEZE UP | DIS. ONLY | Disable only | No alarm indication after Freeze up. After defrost the unit will restart automatically. |
| 1 | FREEZE UP | DIS&SAFETY (default) | Disable and safety | Alarm indication after expire of programmed number of freeze-ups |

The number of allowed freeze-ups, without shutdown of the unit, during a certain period can be set in the menu.

| Line N° | Display | Description | Lower limit | Upper limit | Step | Default |
|---------|---------|----------------------|-------------|-------------|------|---------|
| 2.1 | SAFETY: | Number of freeze-ups | 1 | 5 | 1 | 4 |
| 2.2 | IN | Period (minutes) | 5 | 180 | 1 | 60 |



The system has also the possibility to check the inlet water temperature before reset. If the setting is put on Y, then the system will look at the evaporator outlet water temperature as well as at the evaporator inlet water temperature. If the setting is put on N then the system will only look to the evaporator outlet water temperature.

| Line N° | Display | Description | Possibility | Default |
|---------|--------------------|---|-------------|---------|
| 3 | INL CHECK AT RESET | Evaporator inlet water temperature check before reset | Y/N | N |

When you use inlet check at reset not only the outlet water must rise with 1 steplength but also the evaporator inlet water temperature must rise with 1 steplength

1.6 Lead-lag Control

Introduction

The lead-lag mode determines which circuit starts up first in case of a capacity demand. It prevents the unit from always starting up the same circuit.

Possible modes:

- **Automatic:** The controller decides whether circuit 1 or circuit 2 starts up first.
- **Manual C1 > C2:** Circuit 1 starts up before circuit 2. If circuit 1 is de-activated due to a failure, circuit 2 will start up instead.
- **Manual C1 < C2:** Circuit 2 starts up before circuit 1. If circuit 2 is de-activated due to a failure, circuit 1 will start up instead.

Lead-lag hours in automatic mode

When the lead-lag control is done automatically, the software calculates the differences in operation time between the circuits. When this time is higher than the preset lead-lag hour value, the start sequence of both circuits is swapped. The limit values of the lead-lag hours are the following:

- | lower limit: 100 hours
- | upper limit: 1000 hours
- | default value: 1000 hours

i

This value is important for maintenance purposes. It should be set high enough so that the two compressors (if double circuit) do not require maintenance at the same time and that at least one compressor can remain constantly active.

Equal start up compressors

Yes: both circuits will try to go up in capacity alternating.

No: the leading circuit will try to go to full capacity before the lagging circuit can start up.

1.7 Capacity Limitation

Introduction

This function allows you to limit the capacity of the chiller. Depending on the adjusted mode, it is possible to control the capacity limitation via remote digital input or via a programmable schedule timer.

Remote digital input mode

The circuit that should be able to run can be set in the user setting menu. There are four different possible setting (L1 CIR1 CIR2, L2 CIR1 CIR2, L3 CIR1 CIR2 and L4 CIR1 CIR2). If you want to activate these contacts the Digital Inputs (DI1, DI2, DI3 and DI4) in the service menu should be set as CAP. LIMIT 1, 2,3 or 4.

Schedule timer mode

The schedule timer screen of the user settings menu allows the user to define the capacity limitation setting according to a programmed time.

- | MON, TUE, WED, THU, FRI, SAT and SUN: used to define to which group each day of the week belongs (-/G1/G2/G3/G4).
- | For each of the four groups up to nine actions can be set, each with their respective timing.
- | Beside these four groups there is also a holiday period group which is set the same way as the other groups. Up to 12 holiday periods can be entered in the HD PERIOD screen. During these periods the schedule timer will follow the settings of the holiday period group.

1.8 Pump Control

Introduction

To prevent the chiller to start up without flow, two safety checks are performed. First there is a check to make sure that water flows through the system. Another safety is the double evaporator pump control, in case of failure of one pump the other one takes over. Another advantage of this control is the fact that the system switches from one pump to the other in case failure during operation. The status of the condenser pump can also be indicated via the changeable relay outputs.

Pump lead/lag time

The PUMPCONTROL of the user settings menu allows the user to define the pump-lead time and pump-lag time.

| Line n° | Display | Description | Default value | Limit value |
|---------|--------------|--|---------------|-------------|
| 1 | PUMP CONTROL | Screen title | | |
| 2 | PUMPLEADTIME | Time the water pump will run before starting up the chiller | 020 s | 020-180 s |
| 3 | PUMPLAGTIME | Time the water pump will keep running after stopping the chiller | 000 s | 000-180 s |

Remark: the default value for the PUMPLAGTIME is 0 s but it is recommended to set the lag time to 120s. This is to prevent the evaporator from freezing up.

Automatic pump startup The user will get the choice to perform a pump start every day to prevent obstruction of the pump and to increase its lifetime. Everyday at pump start time, which can be set in the timers menu, the pump will be started automatically for a short period (5s) if the unit is not on.

| Line n° | Display | Description | Default value | Limit value |
|---------|----------|--------------------------------|---------------|-------------|
| 4 | DAILY ON | Activation of daily pump start | N | N-Y |
| 4 | AT | Daily pump start up time | 12h00 | 00h00-24h60 |

Dual evaporator pump control

When dual pump control is allowed an extra digital output is needed (see Service Menu). In total four choices will be possible: one pump (default), two pumps with automatic rotation (by running hours and with a certain offset), priority pump 1 and priority pump 2.

| Line n° | Display | Possible setting | Description |
|---------|-----------------|------------------|---|
| 1 | DUAL EVAP. PUMP | | |
| 2a | MODE | AUTOM. ROTATION | The controller decides whether pump 1 or pump 2 starts up first |
| 2b | MODE | PUMP 1>PUMP 2 | Pump 1 starts up before pump 2 |
| 2c | MODE | PUMP 2>PUMP 1 | Pump 2 starts up before pump 1 |

When the dual evaporator pump control is set in automatic rotation, the software calculates the differences in operation time between the two pumps. When this time exceeds the chosen offset time, the pump will shut down and the other pump will start up, during this the unit keeps running. The switchover will happen immediately, there is no transition time.

| Line n° | Display | Description | Default value | Limit value |
|---------|--------------|----------------------------|---------------|-------------|
| 3 | OFFSET ON RH | Running hours offset value | 048h | 001h-999h |

i

In case two pumps are present (any setting) and the running pump fails then the unit is stopped and started up again with the other pump. When the first pump fails a visible warning will be given. The failed pump can not start up before this warning is reset. If the running pump fails while the other pump is already in warning a unit alarm will be given.

Condenser pump control

It is possible to let the condenser pump work on thermostat control. With this regulation the condenser pump will only be switched on when the unit is cooling (thermostat/compressor on). When no cooling is necessary the condenser pump will be switched off.


When condenser pump control is allowed an extra digital output is needed (see Service Menu)

1.9 Floating setpoint

The floating setpoint can be used to modify the setpoint in function of the ambient temperature.

The user is able to choose to use the floating setpoint or not. The result of using the floating setpoint is that the unit will be used more efficiently and that the modified setpoint will be displayed under the normal setpoint.

1. Source of the floating setpoint outdoor temperature = **floating_source**
2. A reference at which the floating setpoint value is equal to zero = **floating_min** (zero on screen)
3. A reference at which the floating setpoint value is maximum = **floating_max**
4. The maximum floating setpoint value = **floating_maxvalue** (max. value on screen)



Explanation:

When the load of the unit drops (by drop in outdoor temperature) then the setpoint will be changed upwards by the floating setpoint value. Because of this the unit will evaporate at a higher temperature and thus the performance of the unit will be better.

- i** When you use floating setpoint, the value of the setpoint on the readout and set point menu can be different. The readout screen will show the calculated value and the setpoint screen the set value.

1.10 Fan management

1. Purpose

To regulate high pressure

Condenser fans: Number of fansteps


→ single circuit: 3 fansteps

→ double circuit: 2x3 fansteps

| Possible functions | 1. Aircooled cooling only | 2. Evaporatorless unit | 3. Watercooled unit | 4. Condenserless units |
|--------------------|---------------------------|------------------------|---------------------|------------------------|
| | EUWA | ER | EUW | EUWL |
| | CO | CA | HP | RC |
| Fan management | x | x | -- | x |

2. Function description

The fans will work according to following regulation (for three fansteps) :



- The high pressure boundaries (FanLowerLim and FanHigherLim) for the fan control are defined by choice of refrigerant and can be set in the service menu.
- The **fanstepdifference** has a default value of 0,5 bar and can be changed. The **fansteplength** is then calculated by using following formula:

$$\text{fansteplength} = (\text{FanHigherLim} - \text{FanLowerLim}) - (n-1) \cdot \text{fanstepdifference}$$

(with n = number of fansteps, default = 3).

- By choosing the fansteplength big enough, hunting or unstable operation will be avoided.
- With the **fan_timer** (see service menu) it is possible to choose a minimum time between transitions (loadup/loaddown). The default value is 10 seconds. This options is used to increase flexibility and to avoid unstable operation.

Although it is preferred not to work with timers, but with a difference in high pressure, to avoid to high or to low pressures before the controller can react.

- If a changeable digital input is selected as FanSetpoint Shift, following function will be active:
If digital input (RemoteFanShift Yes) is closed , then:
Minimum = FanLowerLim + FanShift
&
Maximum = FanHigherLim + FanShift
Remark:
Maximum Fanshift-value is determined as follows: FanHigherLim + FanShift = HPSetback – 0.5°C.
If this is not the case then FanShift = HPSetback – 0.5°C – FanHigherLim

1.11 EEV driver


1.11.1 Applicable units

All large chillers with pCO²-controller & EEV driver
 EUW(L)*80-100MXY
 EUW(L)*140-200MXY

1.11.2 Basic unit setup

The basic unit is set up to be used in a pLAN network. The customer can add a remote terminal.

A) Basic unit setup (= as standalone)



Example of dipswitch setting

Address 1= 100000
 Address 2= 010000
 Address 3= 110000
 Address 4= 001000

Overview of address of EEV setup:

| | | PCB (pCO ² medium or large) | User terminal (optional) | EEV1 (if present) | EEV2 (if present) |
|--------|---------|--|-----------------------------|----------------------|----------------------|
| Unit 1 | Master | 1 | 2 | 3 | 4 |
| Unit 2 | Slave 1 | 5 | 6 | 7 | 8 |
| Unit 3 | Slave 2 | 9 | 10 | 11 | 12 |
| Unit 4 | Slave 3 | 13 | 14 | 15 | 16 |

1.11.3 *Applicable Parts*

| | Daikin reference | Description | code | rev | How to check revision |
|-----------------|------------------|-------------|------------|----------------|---|
| PCO2 controller | 4SW01021-2 A | PCO2 medium | PCO2DA0BM0 | 1.209 | Sticker on back |
| | 4SW01021-2 C | PCO2 medium | PCO2DA0BM0 | 1.309 or 1.409 | |
| | 4SW01021-3 A | PCO2 large | PCO2DA0BL0 | 1.209 | |
| | 4SW01021-3 C | PCO2 large | PCO2DA0BL0 | 1.309 or 1.409 | |
| EEV driver | 4SW01071-1 | EEV driver | EVD0000000 | 1.015 | Sticker on back Or info menu pCO2 |
| | 4SW01071-1 A | EEV driver | EVD0000000 | 1.018 or 1.019 | |

How to check EEV driver revision in info menu of pCO2 controller:

| EEV driver | Revision | Info menu pCO2 EEV1&2: AAA= hardware version AAABBB BBB=software version |
|------------|----------|--|
| | 1.011 | EEV1:160010 (-> this version is not logic software mistake!) |
| | 1.014 | EEV1:160014 |
| | 1.015 | EEV1:160015 |
| | 1.018 | EEV1:160018 |
| | 1.019 | EEV1:160019 |
| | 1.022 | EEV1:160022 |

1.11.4 *Applicable software*

| | Daikin reference | Description | code | rev | How to check revision |
|------------------------------|------------------|------------------------------|------------|--------|---------------------------|
| PCO2 software large chillers | 4PW13326-x-x | PCO2 software large chillers | FLDKNMCHLA | V1.0M6 | Info menu nr 3 controller |
| | 4PW13326-x-x | PCO2 software large chillers | FLDKNMCHLA | V2.0M6 | |
| | 4PW13326-x-x | PCO2 software large chillers | FLDKNMCHLA | V2.1M6 | |
| | 4PW13326-x-x | PCO2 software large chillers | FLDKNMCHLA | V2.2M6 | |
| | 4PW13326-x-x | PCO2 software large chillers | FLDKNMCHLA | V2.3M6 | |
| | 4PW13326-x-x | PCO2 software large chillers | FLDKNMCHLA | V2.4M6 | |

1.11.5 *Related Software menus*

| | Title | Item |
|-----------------|-------------------|----------------------------------|
| Readout menu | ACT. PRESSURES C1 | LP1 |
| | ACT. PRESSURES C2 | LP2 |
| Service menu | EEV SERVICE MENU | |
| | EEV DRIVER C1(03) | EEV1status |
| | EEV DRIVER C2(04) | EEV2status |
| Alarm menu | 1A9: EEV *** ERR | |
| | 2A9: EEV *** ERR | |
| Info menu | UNIT INFORMATION | EEV1 version parameter |
| | UNIT INFORMATION | EEV2 version parameter |
| I/O status menu | EEV1 IN/OUTPUTS | Battery1 status & Valve position |
| | EEV2 IN/OUTPUTS | Battery2 status & Valve position |

1.11.6 Related LEDs

PCO2 controller (Next to pLAN connection - can be consulted with small mirror on Unit)

pLAN LEDES

| Label | Color | On | Off |
|-------|--------|---|------------------|
| | RED | Error | No error |
| | ORANGE | Communication between pCO2 and 1 or 2 EEV drivers | No communication |
| | GREEN | Communication between pCO2 and 1 or 2 EEV drivers | No communication |

EEV driver (front of EEV driver)

| Label | Color | On | Off | Blinking |
|---------------|-------|---------------------------------------|--|---|
| Power | green | Power supply to EEV driver is present | No power supply to EEV | EEV battery problem active |
| Valve Opening | green | | No valve opening | Valve is opening (not continuously) |
| Valve Closing | green | | No valve closing | Valve is closing (not continuously) |
| Alarm | Red | Alarm is present | No alarm is present | Alarm present (EEV NOT CLOSED Error) |
| pLAN | Green | pLAN operates correctly | pLAN does not operate (no communication) | pLAN does not operate correctly (or busy to initialize) |

If alarm LED & Valve Opening & Valve Closing LED are continuously blinking then the “EEV NOT CLOSED”-alarm is present.

Legend:

Normal operation

1.11.7 Overview alarms

| Circuit Alarms (Circuit will NOT be able to startup) | | |
|--|----------------------|--|
| CIRCUIT1 SAFETY | CIRCUIT2 SAFETY | |
| 1A9:EEV DRIVER ERROR | 2A9:EEV DRIVER ERROR | EEV driver is not found |
| 1A9:EEV NOT CLOSED | 2A9:EEV NOT CLOSED | EEV Valve did not close during stop (for example during power off) Refer to “8. Reset procedure for EEV NOT CLOSED” |
| 1A9:EEV SUPERHEAT ER | 2A9:EEV SUPERHEAT ER | EEV Superheat to low |
| 1A9:EEV EEPROM ERR | 2A9:EEV EEPROM ERR | EEV EEPROM problem |
| 1A9: ST.MOTER ERR | 2A9: ST.MOTER ERR | EEV Step motor problem |
| 1A9:EEV PROBE ERR | 2A9:EEV PROBE ERR | EEV Sensor out of range (LP probe or NTC probe) |

| Network Alarms (Unit will be able to startup) | | |
|---|--|------------------------------------|
| NETWORK SAFETY | | |
| 0U4:PCB COMM.PROBLEM | | Status of the pLAN network is nok. |

| Warnings (Unit/Circuit will be able to startup) | | |
|---|---------------------|---------------------|
| CIRCUIT1 SAFETY | CIRCUIT2 SAFETY | |
| 1A9:EEV BATTERY ERR | 2A9:EEV BATTERY ERR | EEV Battery problem |

1.11.8 *Reset procedures for EEV NOT CLOSED alarm*

(refer also to installation manual)

EEV NOT CLOSED ALARM

Because an “EEV NOT CLOSED” alarm can have a dangerous situation for the unit there is a special procedure to reset this alarm.

1. The service man must check if there is no problem to start the unit (no liquid into the compressor? ...)
2. The service man can consult the reason for the EEV NOT CLOSED alarm in the service menu
Ex.
EEV DRIVER C1(03)
SYSTEM WAITING FOR:
VALVE OPEN
GO AHEAD: NO
3. After this the service man can give a “go ahead” by changing the “NO” into “YES” and confirm (= push ENTER)

After this action the EEV NOT CLOSED alarm can be reset in the ALARM MENU

1.11.9 *Remarks*

- A) EEV errors are delayed after power ON of unit with timer (set in service menu: default 90sec)
This to avoid that an autorestart is prevented by an alarm that happens too fast at the power on of the unit.
- B) PLAN= Internal network between pCO₂ controller / Userterminals & EEV drivers (tx+/tx-/GND)
- C) Change of address is only noticed after power off/on by software (for pCO₂ controller & EEV driver)
- D) Possible to read present pLAN address by using external userterminal (confirm first address setting)
push up/down & enter simultaneous for 10 sec (or 5 sec 2 times after each-other)
(or first 3 menu buttons)
(pCO₂ controller or EEV-driver = square, Userterminal is smaller square)
- E) EEV additional info screens can be activated in service menu

Additional info:

READOUT MENU: Superheat , suction temp.

SETPOINT MENU: Superheat setpoint, pressure setpoint

1.11.10 *Check wiring*

According to wiring diagram of unit

Check especially following items:

1. Tx+/tx- of pLAN connection between pCO₂ controller & EEV1 & EEV2 drivers
2. Power supply VG0 & VG1 of pLAN of EEV driver (VG0 & VG1 -> measure 24 VAC)

1.12 Network hardware overview

1.12.1 Unit setup

The basic unit is setup to be used in a pLAN network. The customer can add a remote terminal.
Basic unit setup (=master)

The optional board to connect the units to the gateway is the Address card EKAC200A

1.12.2 External connections setup.

MODBUS or BACnet connection

The following setups can be used to connect units to a BMS-system through a BMS gateway.

i For more explanation about MODBUS see service manual “BMS option for Daikin network chillers” ESIE99-03

- Multidrop: The gateway can be connected to the BMS making use of the RS485 connection




Fig 3. Multidrop for MODbus

- Point to point: A gateway can be connected to the BMS making use of the RS232 connection




Fig 4. Point to point connection

1.13 DICN (network) Overview

DICN = Daikin Integrated Chiller Network
Also referred to as master-slave system

Remark: In a DICN system (Master-Slave), all the pCO²-controllers must have the same software & code & bios and boot version!

If the master is down (= no power then the network safety and all units will work as standalone (no parameters transferred)

Basic principle:

- No ER-units in a DICN-system
- Possible to combine all air-cooled in one DICN-system
- Possible to combine all water-cooled in one DICN-system
- Max to combine 4 units in one DICN-system


| | 1. ER units | 2. Aircooled units: 1 circuit | 3. Aircooled units: 2 circuits & 1 evap | 4. Aircooled units: 2 circuits & 2 evap | 5. watercooled units: 1 circuit | 6. watercooled units: 2 circuits & 2 evap |
|---|-------------|-------------------------------|---|---|---------------------------------|---|
| 1. ER units | - | - | - | - | - | - |
| 2. Aircooled units: 1 circuit | - | X | X | X | - | - |
| 3. Aircooled units: 2 circuits & 1 evap | - | X | X | X | - | - |
| 4. Aircooled units: 2 circuits & 2 evap | - | X | X | X | - | - |
| 5. watercooled units: 1 circuit | - | - | - | - | X | X |
| 6. watercooled units: 2 circuits & 2 evap | - | - | - | - | X | X |

X = these units can be connected and mixed in one DICN-system

PLAN: Transfer all parameters to the different units (only if MSOption = yes)

- DICN Basic setup (= master/slave system)

In service menu, the installer must select if the units are used in a MS system or not.



Overview of addresses of DICN setup:

| | | PCB (pCO ²) | Userterminal (optional) | EEV1 (if present) | EEV2 (if present) |
|--------|---------|----------------------------|----------------------------|----------------------|----------------------|
| Unit 1 | Master | 1 | 2 | 3 | 4 |
| Unit 2 | Slave 1 | 5 | 6 | 7 | 8 |
| Unit 3 | Slave 2 | 9 | 10 | 11 | 12 |
| Unit 4 | Slave 3 | 13 | 14 | 15 | 16 |

You can find the dipswitch of the EEV driver on the inner side of the driver. Take off the cap of the EEV driver (cap with the led's). If you have removed it, you will find on the inner side of the cap the address dipswitch. Set the dipswitch address and close the EEV driver again.

1.13.1 On/Off management

For DICN units (when MS option is yes):

The different units can be put in "NORMAL or STANDBY" mode or in "DISCONN. ON/OFF" mode

MSOption see page 22

| | MSOption = yes (network unit) | | MSOption = no (standalone unit) |
|--------------------------------|--|--|--|
| | NORMAL or STANDBY | DISCONN.ON/OFF | |
| On/Off status | Equal for all units that are in "NORMAL/STANDBY" mode | Dedicated to this unit only. | Dedicated to this unit only. |
| Changing On/Off status | When you push the ON/OFF button on a unit that is in "NORMAL/STANDBY" mode. The status (ON/OFF) will be transferred to all the other units in "NORMAL/STANDBY" mode | Push On/Off button, the status (On/Off) is dedicated to this unit only. | Push On/Off button, the status (On/Off) is dedicated to this unit only. |
| Changing Remotely On/OF status | Into the service menu of the master, you can select a changeable Digital Input as "Remote On/Off" | Into the service menu of that unit, you can select a changeable Digital Input as "Remote On/Off" | Into the service menu of that unit, you can select a changeable Digital Input as "Remote On/Off" |
| | Remark: 1 If the master is "DISCONN.ON/OFF" then the DI will change the On/Off status of the master & all the units with "NORMAL/STNADBY" mode. 2 If a slave (=not the master) is "NORMAL/STNADBY" and the DI= "Remote On/Off" then the DI of that slave will not change the On/Off status of the unit & all the "NORMAL/STNADBY" units. | | |

Remark:

If you work with an REMOTE ON/OFF switch and you start up the unit. It can be that the unit doesn't start up. Only the ON/OFF button starts to blink, In that case check the REMOTE ON/OFF if he is ON. Switch ON and the Start Unit.

1.13.2 *Changeable DI management*

| | MSOption = yes (network unit) | MSOption = no (standalone unit) |
|--|---|---|
| Dual setpoint | DI of Master | DI of Unit |
| Remote On/Off | DI of Master | DI of Unit |
| Remote Cooling/Heating (only for watercooled units) | DI of Master | DI of Unit |
| Capacity limitation 1/2/3/4 | DI of unit | DI of Unit |
| FanSetpointShift | DI of unit | DI of unit |

1.13.3 *Cooling heating Management*

Cooling mode: thermostat function on evaporator

Heating mode: thermostat function on condenser

Double thermostat: thermostat function on evaporator and condenser

| | MSOption = yes (network unit) | MSOption = no (standalone unit) |
|------------------------------------|--|---|
| ModeCH | Equal for all units. | Dedicated to this unit only |
| Changing ModeCH | When you change the ModeCH on one unit. Then the status is transferred to all units | When you change the ModeCH on a unit. Then the status is NOT transferred to other units |
| ModeCH status | Equal for all units | Dedicated to this unit only. |
| Changing remotely ModeCH status | Into the service menu of the master, you can select a changeable Digital Input as "Remote C/H" | Into the service menu of that unit, you can select a changeable Digital Input as "Remote C/H" |
| | Remark: If in a slave (=not the master) DI= "Remote C/H" is changed then the DI of that slave will not change the modeCH status | |

1.13.4 *Schedule timer Management*

The schedule timers consists out of 5 different groups of 9 actions.

4 different groups can be applied to a weekday.

1 group can be applied on different holiday periods.

For DICN units:

- only possible to set in master (screens not available on slave units if MSOption =yes)
- if master is down (=no power) then the schedule of master is not executed and each slave that working as stand-alone (& network alarm) in latest status.
- ***If the LIM1 is activated in the schedule timer in the master, this is transferred to all DICN units (same for LIM2/3/4/NO LIM)***

1.13.5 *Limitation management*

| | MSOption = yes (network unit) | MSOption = no (standalone unit) |
|--|---|---|
| Limitation Mode | Equal for all units | Dedicated to this unit only. |
| Changing Limitation mode | When you change in one unit. Then the value is transferred to all units | When you change in each unit. Then the value is NOT transferred to other units |
| Active limitation by Schedule timer | Set schedule timer of Master. (see remark 1) Then when activation of limitation, it will be transferred to all units. | Set schedule timer of unit Dedicated to this unit only. |
| Enable/disable limitation By remote digital inputs | Into the service menu of each unit, you can select a changeable Digital Input. Dedicated to this unit only. | Into the service menu of each unit, you can select a changeable Digital Input. Dedicated to this unit only. |
| | Remark: 1. schedule timer is only available in Master | |

1.13.6 *Free cooling*

When ambient temperature is low, cool water can be made easily by direct heat exchange with ambient air. Free cooling can work on Ambient or difference between inlet water temperature and ambient temperature. When free cooling is activated a 3 way valve will be closed.

Free cooling can only be used if the changeable digital output “free cooling” is selected. Free cooling function only if unit is on.

With a DICN network:

If MSOption = yes then the function is executed by the master on the ambient sensor by the master.

If MSOption = no then the function is executed as a standalone unit.

Remark:

If the DO: Freecooling is selected in a slave then the function will only be executed if the MSOption = no

1.13.7 *Dual setpoint Management*

| | MSOption = yes (network unit) | MSOption = no (standalone unit) |
|--|--|--|
| Setpoint value (1&2) | Equal for all units | Dedicated to this unit only. |
| Changing setpoint value | When you change the setpoint of one unit. Then the value is transferred to all units | When you change the setpoint of each unit. Then the value is NOT transferred to other units |
| Dual setpoint status | Equal for all units | Dedicated to this unit only. |
| Changing remotely dual setpoint status | Into the service menu of the master, you can select a changeable Digital Input as “Dual setpoint” | Into the service menu of that unit, you can select a changeable Digital Input as “Dual setpoint” |
| | Remark: 1. If in a slave (=not the master) DI=“Dual setpoint” then the DI of that slave will not change the dual setpoint status 2. If the slave is standalone (= if MSOption = No), no setpoints are transferred and dualsetpoint from the unit changes the status | |

1.13.8 *Manual Management*

In manual mode the customer can manually start up the different compressors in all capacity steps & fans in all fansteps.

In manual mode No capacity limitation & timers!

No Freeze-up prevention

No HP setback

| | NORMAL or STANDBY | DISCONN. ON/OFF |
|-------------------------|--------------------------|------------------------------------|
| Manual mode | Not possible | Dedicated to this unit only. |
| Changing to manual mode | Not possible | Possible to select in usersettings |

1.13.9 *Automatic thermostat management*

General rule for inlet outlet manual mode

1. Manual mode only possible in disconnected mode and not transferred to other units.
2. Inlet/outlet transfer to all normal units and “disconnected units with no manual mode”.

| | MOption = yes (network unit) | | MOption = no (standalone unit) |
|--------------------------|--|---|---|
| | NORMAL or STANDBY | DISCONN.ON/OFF | |
| Inlet/outlet mode | Equal for all units | Equal for all units | Dedicated to this unit only. |
| Changing to Inlet/Outlet | When you change the Inlet/outlet mode in an unit. Status is transferred to all other units Except units that are in (“DISCONN.ON/OFF” mode and manual mode) | When you change the Inlet/outlet mode in a unit. Status is transferred to all other units Except units that are in (“DISCONN.ON/OFF” mode and manual mode) | When you change the Inlet/outlet mode in that unit. No status is transferred to other units |

1.13.10 *External thermostat Management*

No DICN option is possible (-->MSOPTIONSETTING=NO & not visible)

1.13.11 *Pump management*

DICN units (MOption =yes):

1. Pump on if “UNIT ON”: closing pumpcontact when pumplead timer is running (started when unit is turned ON), open pumpcontact after pumplagtimer (pumpfunction as for standalone unit).
2. Pump on if “COMPR ON” : close pumpcontact when pumplead timer is running (started when loadup request is yes), open pumpcontact after pumplagtimer (started when no compressors are running anymore)

DICN units (MOption =yes): Extra pump procedure!

If no pumpcontact is closed (ex all pump on if “ COMPR ON” & no request to loadup) then turn on the pumpcontact of the unit with highest priority.

(This is needed because the temperature sensor must be able to measure the correct water temperature.

1.13.12 *Pumpdown*

For DICN units: only possible to enter if unit is “MODE: DISCONN.ON/OFF” and unit is OFF.

1.13.13 Priority Management

Determine unit priority for each unit in a M/S system.

Basic rules:

- Loadup as fast as possible
- Use as less possible units

The following items are considered to determine priority

- Standby function
- According to loadup/down request possible, outlet water temp, unit priority, unit running , unit offset

Standby function:

Determine actual standby unit:

| | |
|---|---|
| If only one unit is in “STANDBY” mode | • ActualStandby = unit in “STANDBY” mode |
| If more than one unit is in “ STANDBY” mode | From all units in “STANDBY” mode that have step=0 • Actual Standby = Select Unit with biggest RunnHours-offset |

Determine if actual standby unit is needed:

| | | | |
|-----------------------|--|----|--|
| Standby needed Yes if | <ul style="list-style-type: none"> • All units are 100% • All units are (0% or 100%) and as the standbyunit is not equal to 0% • A unitsafety is present on a unit • A circuitsafety is present on a unit • “DISCONNECT ON/OFF” is selected on a unit | OR | Then Loadup possible (standby Unit) = yes |
| | | | |

Determine priority for each unit according to

1. loadup request

| | LOW Priority | | High priority | |
|--|--|---|--|--------------------------------------|
| 1. Unit Loadup possible | NOT (Loadup possible) | | Loadup possible | |
| 2. Unit Outlet water temperature | Outlet temp(unit) < MOW + stepLPriority * steplenght | | NOT (Outlet temp(unit) < MOW + stepLPriority * steplenght) | |
| 3. Unit priority | 0 (lowest priority) | 1 | 2 | 3 (highest priority) |
| 4. Unit that are already running | NOT (unitstep<=0) | | Unitstep<=0 | |
| 5. unit offset (running hours - RHOOffset) | Highest (running_hours - RHOOffset) | > | > | Smallest (running_hours - RHOOffset) |

2. loaddown requested

| | LOW Priority | | High priority | |
|--|--|----------------------|--------------------------|---------------------------------------|
| 1. Unit Loaddown possible | NOT (Loadup possible) | | Loadup possible | |
| 2. Unit Outlet water temperature | NOT (OUTLET TEMP(Unit) < MOW | | OUTLET TEMP(Unit) < MOW | |
| 3. Unit on step 1 | Unit step = 1 & all other units are running on 0 or 100% | NOT (unitstep = 1) | Unit step =1 | |
| 4. Standby Unit | NOT (Unit = ActualStandby) | | Unit = ActualStandby | |
| 5. unit offset (running hours - RHOOffset) | 3 (lowest priority) | 2 | 1 | 0 (highest priority) |
| 6. unit offset (running hours - RHOOffset) | Smallest (running_hours - RHOOffset) | < | < | Highest (running_hours - RHOOffset) |

Into the service menu you can specify the “MS PR (Unit Priority) –(StepLPriority)” this value is used to select the priority. The priority depends on different points. See above.

1.13.14 *Changeable analogue input management*

This concerns AI3 setting.

If the unit is a standalone the AI3 setting of the unit is chosen.

If the master slave option of the unit is activated, then the AI3 setting will be the AI3 setting of slave1!

Because, in DICN, the AI3 of the master will be used for the mixed outlet temperature.

1.14 Free cooling

When ambient temperature is low, cool water can be made easily by direct heat exchange with ambient air. Free cooling can work on Ambient or difference between inlet water temperature and ambient temperature. When free cooling is activated a 3 way valve will be closed.

Free cooling can only be used if the changeable digital output “free cooling” is selected. Free cooling function only if unit is on.

1.14.1 Free cooling on ambient temperature


it is possible to work with indirect or direct free cooling on ambient temperature

Indirect free cooling

No free cooling


- compressor on
- evaporator waterpump on CHWP
- digital output for 3-way valve opens

with a certain leadtime between opening 3-way valves and starting of compressor



Free cooling

- compressor off
- evaporator waterpump on CHWP
- digital output for 3-way valve closed




No free cooling : CHWP pumps load through evaporator of the chiller. The cooling tower is disconnected from the system through the 3-way valve.

Free cooling : CHWP pumps load through external heat exchanger. The chiller is disconnected through the 3-way valves. The cooling tower cools the heat exchanger (pump CWP is running)


Direct free cooling

No free cooling
 -compressor on
 -evaporator waterpump on CHWP
 -digital output for 3-way valve opens

With a certain leadtime between opening 3-way valves + starting of pump and starting of compressor




Free cooling
 -compressor off
 -evaporator water pump **off** CHWP
 -digital output for 3-way valve closed



Pump CWP will work if **free cooling** is selected. Chiller is disconnected through 3-way valve. Pump CHWP is also disconnected by-passed through 3-way valve.

Pump CHWP will work if **no free cooling** is selected. Cooling tower is disconnected through 3-way valve.

1.14.2 *Free cooling on difference between entering water evaporator and ambient temperature.*



1.15 Changeable analogue input.

This function is similar to the floating setpoint function, in that way that it also modifies the setpoint. But this time the modification is function of an electrical signal and not the ambient temperature. Possible signals are: 0/1 V; 0/10 V; 0/20mA; 4/20mA

Function description




Fig. example setp.signal 0-1V

- The function can be activated in the service menu
 - Not active: Analogue signal is not used.
 - Active: Analogue signal is used to change user setpoint.
 - When the function is activated you can set the maximum setpoint signal difference. Default this is set to 0 and it can be set to a value from -50 to 50.
- Example for 0-1V signal:
- If analogue input AI3 is 1V then SetpSignalDiff is equal to SetpsignalDiffMax
 - If analogue input AI3 is 0V then SetpSignalDiff is equal to 0

Remark:

The actual setpoint displayed in the readout menu is the result of the combination of following functions:

- Dual setpoint function
- C/H Mode and inlet/outlet mode
- Setpoint signal mode.

Example:

| Situation (setp.signal 0-1V) | Calculation | Result |
|---|--|---|
| Cooling inlet mode, SetpSignalDiffMax= 8,0°C | Setpoint1(inlet,evap)=12,0°C AI = 0.5 V | SetpSignalDiff= 4.0 °C Setpoint=16,0°C |

2 The digital Controller for the Large Chillers

2.1 What Is in This Chapter

Introduction In this chapter you will learn to work with the controller pCO² for the chiller types.



Overview This chapter covers the following topics:


| Topic | See page |
|---|----------|
| 2.2 – The Controller | 34 |
| 2.3 – Start/Stop, Cool/Heat and Temperature Settings | 39 |
| 2.4 – What happens in case of an Alarm or a Warning | 40 |
| 2.5 - Menu Overview | 41 |
| 2.6 – How to Read or Adjust Parameter Settings: the Programming Procedure | 42 |
| 2.7 – Read-out Menu | 43 |
| 2.8 – Set Points Menu | 46 |
| 2.9 – User Settings Menu | 48 |
| 2.10 – Timer Menu | 67 |
| 2.11 – Safety & History Menu | 69 |
| 2.12 – Info Menu | 73 |
| 2.13 – Input/Output Status Menu | 76 |
| 2.14 – User Password Menu | 81 |
| 2.15 – Cool/Heat Menu | 82 |
| 2.16 – Network Menu | 83 |
| 2.17 – To adjust the contrast of the display | 84 |
| 2.18– To enter the pumpdown menu | 85 |

2.2 The Controller

Digital controller The EUW(A)(L)40~200M(Z)(X) units are equipped with a digital controller offering a user-friendly way to configure, use and maintain the unit. The digital controller consists of:

- ∣ A alphanumeric LCD display
- ∣ 6 keys (4 of them are colored when activated)

Front panel The illustration below shows the front panel of the controller.



| key | Description | LED Color |
|-----|--|-----------|
| | Key to enter the safeties menu or to reset an alarm | Red |
| | Key to enter the main menu | Green |
| | Key to start up or to shut down the unit | Green |
| | Key to scroll through the screens of a menu (only in case v, : or ^ appears) or to rise, respectively lower a setting. | - |
| | | |
| | Key to confirm a selection or a setting | Green |

How to switch between Screens


Each menu contains a number of screens. You can switch between screening using the or keys. In the upper-left corner of the screen you will find a screen indicator, indicating whether there is a previous or next screen. An overview is given below:

| The screen indicator | Indicates that you can |
|----------------------|--|
| ^ | return to the previous screen |
| v | go tot the next screen |
| / | either return to the previous or go to the next screen |

i note : Temperature read out tolerance : $\pm 1^{\circ}$

Screen detail

Each screen contains 4 lines which give information about a setting (a description and an entry field). The entry fields can be adjusted using the ▲ and ▼ keys. The cursor is marked by the sign _ . You can move the cursor between the screen indicator and the entry fields using the ← key. You can move the cursor directly to the screen indicator by pressing ⏪



i note: Make sure that the cursor is at the screen indicator position when scrolling through the screens.

2.2.1 Version of software.

| | | |
|-------------------|----------------|--|
| Software version: | X x.xM6 (date) | X: "V" = Final software, "A" = Alfa software, "B" = Beta software x.x: progressive number "M" = Multilanguage "6" = Hardware code for pCO ² |
| Software code: | FLDKNMCHLA | "FL" = software for pCO ² "DKN" = Daikin Europe NV "M" = Multilanguage "CHL" = Large Chiller applications "A" = Setup code for pCO ² |
| Boot version: | V x.xx (date) | x.xx: progressive number |
| Bios version: | V x.xx (date) | x.xx: progressive number |

Remark: In a DICN system (Master-slave), all the pCO²-controllers must have the same software code & bios & boot version!

**The manual is based on the software version V2.4M6
Other software versions can have different displays**

2.2.2 *Range of application.*

▪ **Large aircooled chillers :**

- Single circuit (PCO² MEDIUM) 3step compr. : EUWA*40-60MZY
EUWA*40-60MXY
ER*40-60MZY
- Single circuit (PCO² MEDIUM) 4step compr. : EUWA*80-120MZY
EUWA*140MZY
- Double circuit (PCO² LARGE) single evaporator : EUWA*80-120MXY
- Double circuit (PCO² LARGE) double evaporator : EUWA*160-200MZY
EUWA*160-200MXY

▪ **Large watercooled chillers :**

- EUW single circuit (PCO² MEDIUM) : EUW*40-60MXY
EUW*80-100MXY
- EUW double circuit (PCO² LARGE) : EUW*120MXY
EUW*140MXY
EUW*160-200MXY

▪ **Large condenserless chillers :**

- EUWL single circuit (PCO² MEDIUM) : EUWL*40-60MXY
EUWL*80-100MXY
- EUWL double circuit (PCO² LARGE) : EUWL*120MXY
EUWL*140MXY
EUWL*160-200MXY

2.2.3 *General features of the medium and large controller*

Remark:

Features common to all the versions

- 16-bit microprocessor, 14 MHz, internal registers and 32 bit operation, 512 Byte internal RAM;
- up to 6 MByte FLASH MEMORY per program;
- 256 kByte static RAM, upon prior request expandable to 1 MByte;
- 1 RS485 serial port for pLAN;
- ready for connection to RS485 supervisory network;
- clock with replaceable lithium battery;
- 56 Byte of battery backed-up RAM;
- selection of address and LEDs for pLAN and LED power signal.;
- DIN plastic case for installation on omega rail;
- 24Vac/Vdc power supply;
- telephone connector for pCO terminals and synoptic;

pCO² LARGE (18 DIN modules)



- 14 optically -isolated digital inputs, 24Vac 50/60Hz or 24Vdc;
- 4 optically -isolated digital inputs, 24Vac/Vdc or 230Vac (50/60Hz);
- 18 relay digital outputs (3 of which with changeover contacts);
- 4 analogue inputs, selectable between NTC, PT1000, ON/OFF;
- 6 analogue inputs, selectable between NTC, 0÷1V, 0÷10V, 0÷20 mA, 4÷20mA;
- 6 analogue outputs, 0÷10 V;
- 1 serial port for I/O expansion.

pCO² MEDIUM (18 DIN modules)



- 12 optically -isolated digital inputs, 24Vac 50/60Hz or 24Vdc;
- 2 optically -isolated digital inputs, 24Vac/Vdc or 230Vac (50/60Hz);
- 13 relay digital outputs (3 of which with changeover contacts);
- 2 analogue inputs, selectable between NTC, PT1000, ON/OFF;
- 6 analogue inputs, selectable between NTC, 0÷1V, 0÷10V, 0÷20 mA, 4÷20mA;
- 4 analogue outputs, 0÷10 V.

2.2.4 Procedure : software upload/download

Copy from key to pCO²



- Switch off the pCO² and remove the “expansion memory” cover with a screwdriver (see Fig. 2)
- Set the key selector on 
- Insert the key in the corresponding pin connector as shown. (see Fig. 3)
- Press simultaneously the buttons UP and DOWN then supply power to the pCO²
- Check the LED on the key is on (red color )
- Wait until the request of copying appears on the LCD display, then release the buttons and confirm by pressing ENTER.
- The data transfer operation takes about 50s using the 1MB key and 100s using the 2MB one. the display will show a progressive series of numbers.
- Once copied the application program starts, then switch off the pCO², remove the key, put the cover in its place and switch on the pCO² again,
- Now the pCO² works with the program transferred by the key.

Copy from pCO² to key

- Switch off the pCO² and remove the “expansion memory” cover with a screwdriver (see Fig. 2)
- Set the key selector on 
- Insert the key in the corresponding pin connector as shown. (see Fig. 3)
- Press simultaneously the buttons UP and DOWN then supply the pCO²
- Check the LED on the key is on (green color )
- Wait until the request of copying appears on the LCD display, then release the buttons and confirm by pressing ENTER.
- If the application includes a password to protect the software, use the UP and DOWN buttons on the terminal to enter the correct password. Then press enter.
- The data transfer operation takes about 50s using the 1MB key and 100s using the 2MB one. the display will show a progressive series of numbers.
- Once copied the application program starts, then switch off the pCO², remove the key, put the cover in its place and switch on the pCO² again,
- Now the key has the program transferred by the pCO².

Copy from WinLoad32 to Key

Optional: Carel RS Converter (software Winload + drivers : Will be available on intranet)

- Switch off the pCO² and remove the “expansion memory” cover with a screwdriver (see Fig. 2)
- Set the key selector on  (from key to pCO²)
- Insert the key in the corresponding pin connector as shown. (see Fig. 3)
- Prepare the connection for downloading the program for WinLoad32.
- Supply power to the pCO² (check the red LED on  the key is on)
- Make the upload
- Once finished, switch off the pCO², remove the key and put the cover in its place.
- Now the key has the program transferred from WinLoad32.




Fig. 2




Fig. 3

2.3 Start/Stop, Cool/Heat and Temperature Settings

Power on | The initialization takes 10 seconds
 | The controller automatically goes to the menu overview.

Remote start/stop The procedure to start or stop the unit depends on the settings of the remote start/stop,

note The remote start/stop is field supply.

How to start or stop

| Local key | Remote Switch | Unit | Ⓛ LED |
|-----------|---------------|------|----------|
| ON | ON | ON | ON |
| ON | OFF | OFF | Flashing |
| OFF | ON | OFF | OFF |
| OFF | OFF | OFF | OFF |

How to cool or heat To change from cooling to heating (or visa versa) you have to enter the Cooling/Heating menu through the main menu.

Emergency stop In event of emergency, switch of the unit by pushing the emergency button.

Temperature setting To adjust the inlet or outlet water temperature, go to the Set Points menu through the main menu.

Remark To prevent the unit from starting up at 100%, the unit will always loaddown to 12% and operate at this capacity for a couple of seconds before shutting down.

2.4 What Happens in Case of an Alarm or a Warning

Introduction The units are equipped with four kinds of safety devices: unit safeties, Circuit safeties, network safeties and dual pump safety.

Overview safeties


| Unit safety | Description | Safety possible if unit is off? |
|----------------------------------|--|---------------------------------|
| 1. Inlet Condenser sensor error | +Er / -Er readout by sensor | Y |
| 2. Inlet Evaporator sensor error | +Er / -Er readout by sensor | Y |
| 3. Reverse phase protector | Safety is activated if digital input is closed | Y |
| 4. Flow stopped | Safety is activated if digital input is longer open then 5 seconds | N |


| circuit safety | Description | Safety possible if unit is off? |
|-----------------------------------|--|---------------------------------|
| 1. Outlet Evaporator sensor error | +Er / -Er readout by sensor | Y |
| 2. General module safety | Safety is activated if digital input is opened | Y |
| 3. Freeze-up module safety | Safety is activated if digital input is closed | Y |



| Network safety | Description | Safety possible if unit is off? |
|-------------------------------|--|---------------------------------|
| 1. PCB Communication problems | Safety is activated if network status is not OK. (Only possible if a network of different controllers exist) | Y |

| Dual pump safety | Description | Safety possible if unit is off? |
|------------------|--|---------------------------------|
| 1. Flow stopped | Safety is activated if digital input is longer open then 5 seconds | N |

i note


Press the  key when the alarm is activated.

The appropriate safety screen with the basic information appears. Press the  key to see the detailed information.

If more than one kind of safety is active (indicated by means of ^, v or ÷), use the  and  keys to consult them.

2.5 Menu Overview


Introduction This chapter gives an overview of the screens provided by the different menus.



2.6 How to Read or Adjust Parameter Settings: the Programming Procedure

Programming procedure

The following flow chart explains the way to program:



(*): The display shows the last screen used

2.7 Read-out Menu

Operational information Using this menu you can read the operational information, such as the cooling set points, the inlet and outlet water temperature, the circuit status, etc. This menu allows access to several screens. The number of screens depends on the unit type and the options

Screen 1 This screen shows information about the operation mode, the set points and the temperatures:
Line 4 is only visible if the unit is a “HP”.
No line 2, 3, 4 if unit type is a “CA”

| Line n° | Display | Description |
|---------|----------------|---|
| 1a | INLSETP1 (2) E | Evaporator inlet water temperature setpoint 1 (or setpoint 2 in case of dual setpoint setting). |
| 1b | OUTSETP1 (2) E | Evaporator outlet temperature setpoint 1 (or setpoint 2 in case of dual setpoint setting). |
| 1c | MANUAL MODE | If the controller is programmed in manual control |
| 1d | INLSETP1 (2) C | Condenser inlet temperature setpoint 1 (or setpoint 2 in case of dual setpoint setting). |
| 1e | SP1(2)E: C: | Set point 1 Evaporator: Condenser: (or setpoint 2 in case of dual setpoint setting) . |
| 1f | THERMOSTAT | The unit works on thermostat control |
| 2 | INL WATER E | Actual evaporator inlet water temperature. |
| 3 | OUTL WATER E | Actual evaporator outlet water temperature. |
| 4 | INL WATER C | Actual condenser inlet water temperature |

Note: You can select setpoint 1 or 2 with an input from a switch. Into the service menu you can select which input you want to use for the selection. Choose an input and select DUAL SETPOINT

Screen 2 This screen shows information about the evaporator outlet water temperature:

| Line n° | Display | Description |
|---------|-----------------|--|
| 1 | EVAPORATOR | Evaporator related data. |
| 2 | OUT WATER C1 | Actual evaporator outlet water temperature of circuit 1 |
| 3 | OUT WATER C2 | Actual evaporator outlet water temperature of circuit 2. |
| 4 | THERMOSTAT STEP | Indicates the actual capacity step (number of steps is programmable) |

Screen 3 This screen shows information about the status of compressors C1 or C2

| Line n° | Display | Description |
|---------|--------------|------------------------------------|
| 1 | UNIT STATUS | Compressor status data |
| 2 | C1 | Actual status of compressor 1 |
| 3 | C2 | Actual status of compressor 2 |
| 4 | UNITCAPACITY | Indicates the actual capacity use. |

The possible status of a compressor can be:

| Display | Description |
|--------------------|---|
| OFF-CAN STARTUP | The compressor is ready to start up when extra cooling is requested. |
| OFF-TIMER BUSY. | One of the software timers is counting. Compressor cannot start up. |
| ON-12% STAR | Compressor works on 12% in star |
| ON – XX% DELTA | Compressor works on XX% on delta |
| ON – YY% (LIMIT) | Compressor works on YY% and reaches the limit specified in user settings menu |
| OFF–SAFETY ACTIVE. | One of the safeties prevents starting of the compressor. |
| OFF–0% LIMIT | Compressor is disabled, to limit the unit capacity. This can be activated with a schedule timer or as a remote digital input. |
| OFF–FREEZEUP DIS | The compressor is shut off due to freeze up problems. |

- i Possible values for XX are 12%, 25% (if available), 40%, 70%, 100%
Possible values for YY are 25% (if available), 40%, 70%, 100%

Screen 4 This screen shows information about the pressures of circuit 1:

| Line n° | Display | Description |
|---------|---------------------------|--|
| 1 | ACT. PRESSURES C1 | Pressure data of circuit 1 |
| 2 | HP1: b = °C | Actual high pressure and corresponding temperature |
| 3 | LP1: b = °C | Actual low pressure and corresponding temperature |

Screen 5 This screen shows information about the pressures of circuit 2:

| Line n° | Display | Description |
|---------|---------------------------|--|
| 1 | ACT. PRESSURES C2 | Pressure data of circuit 2 |
| 2 | HP2: b = °C | Actual high pressure and corresponding temperature |
| 3 | LP2: b = °C | Actual low pressure and corresponding temperature |

Screen 6 This screen shows information about the compressor running hours:
Line 4 will only be visible if unit type <>"HP"

| Line n° | Display | Description |
|---------|---------------|--|
| 1 | EXTRA READOUT | Compressor running hours. |
| 2.1 | RH 1 | Total running hours of compressor 1 |
| 2.2 | CS 1 | Total amount of start-ups of compressor 1. |
| 3.1 | RH 2 | Total running hours of compressor 2 |
| 3.2 | CS 2 | Total amount of start-ups of compressor 2. |
| 4 | AMBIENT | Actual ambient temperature |

Screen 7 and 8 These screens shows information about the EEV.
Only visible if EEV screens = YES and EEV = YES

| Line n° | Display | Description |
|---------|-------------------|---|
| 1 | EEV 1 (2) READOUT | Readout off EEV driver of circuit 1 or 2 |
| 2 | SUCTION TEMP: | Actual suction temperature (unity: 0.1°C) |
| 3 | SUPERHEAT: | Actual superheat temperature (unity: 0.1°C) |

2.8 Set Points Menu

Screen 1: password Depending on the settings in screen 14 of the user settings menu explained on page 59, the system may require the password to enter the screens in this menu.
Visible if password Setpoint menu = YES.

| Line n° | Display | Description |
|---------|----------------|----------------------------|
| 1 | ENTER PASSWORD | Screen title |
| 3 | PASSWORD: 0000 | Enter the correct password |

i note the units leave the factory with the password 0000

Screen 2 This menu allows you to set the inlet and outlet water temperature of the evaporator of circuit 1 and 2. These set points will not be active in the Manual Control Mode.

| Line n° | Display | Description | Default value | Limit value | Step value |
|---------|-------------|---|---------------|-----------------|------------|
| 1 | INLSETP1 E | Inlet water temp. set point 1 evaporator | 12.0 °C | (MOW+3) – 23 °C | 0.1 K |
| 1a | INLSETP1 C | Inlet water temp. set point 1 Condenser | 12.0 °C | 15 – 50 °C | 0.1 K |
| 2 | INLSETP2 E | Inlet water temp. set point 2 evaporator | 12.0 °C | (MOW+3) – 23 °C | 0.1 K |
| 2b | INLSETP2 C | Inlet water temp. set point 2 Condenser | 12.0 °C | 15 – 50 °C | 0.1 K |
| 3 | OUTLSETP1 E | outlet water temp. set point 1 evaporator | 7.0 °C | MOW – 16 °C | 0.1 K |
| 4 | OUTLSETP2 E | outlet water temp. set point 2 evaporator | 7.0 °C | MOW – 16 °C | 0.1 K |

Line 1, 2, 3, 4: Water and Aircooled units: Cooling mode(Inlet/Outlet/Manual)

Line 1a, 2a: only for Water Cooled units: Heating mode(Inlet/Manual)

Line 1, 2, 1a, 2a: only for water cooled units: Double thermostat (Inlet/manual)



You can select set point 1 or 2 by remote dual set point switch (Digital Input) if installed.

I note

- | The limit values mentioned in the upper table is valid for the standard MOW (Minimum Outlet Water) setting of 5°C.
- | For glycol units the lower limit of the cooling temperature set point depends on the MOW setting. The possible MOW settings for glycol units are: 2°C, 0°C, -5°C and -10°C.

Screen 3 This menu allows you to set the EEV set points.
Only visible if EEV screen = Yes

| Line n° | Display | Description | Default value | Limit value | Step value |
|---------|---------------|--------------------------------|---------------|-------------|------------|
| 1 | EEV SETPOINTS | | | | |
| 2 | SH SP1: 2: | Superheat setpoint | 5 °C | 0 – 9.9 °C | 0.1 °C |
| 3 | PR SP1: 2: | Pressure setpoint of superheat | 3.5 bar | 0 – 7 bar | 0.1 bar |


Screen 4

This menu allows you to set the EEV set points.
Only visible if EEV screen = Yes

| Line n° | Display | Description | Default value | Limit value | Step value |
|---------|---------------|------------------------|---------------|----------------|------------|
| 1 | EEV SETPOINTS | | | | |
| 2 | MINOP1: 2: | Min operation pressure | 0 bar | 0 – MAXOP bar | 0.1 bar |
| 3 | MAXOP1: 2: | Max operation pressure | 6.5 bar | MINOP – 30 bar | 0.1 bar |

Between the min and the max operation pressures the unit will regulate on superheat setpoint.

- EVV basic operation



2.9 User Settings & ServiceMenu

2.9.1 User Settings Menu

Screen 1: password You need the password to enter this menu. The unit leaves the factory with password 0000.

| Line n° | Display | Description |
|---------|----------------|----------------------------|
| 1 | ENTER PASSWORD | Screen title |
| 3 | PASSWORD: 0000 | Enter the correct password |

i note the units leave the factory with the password 0000



To create your own password, refer to page 81

Screen 2 This screen allows modification of the control settings:

| Line n° | Display | Description | Possible settings |
|---------|------------------|--|---|
| 1 | CONTROL SETTINGS | screen title | |
| 2 | MODE: | to select the control mode | MANUAL CONTROL INL WATER STEP OUTL WATER STEP EXTERNAL THERM |
| 3 | CIR1: CIR2: | status of corresponding compressor (only for manual mode) | 0% 25% 40% 70% 100% |
| 4 | F1*: F2*: | status of corresponding fan speed (only for manual mode) | OFF / LOW / MED / HIGH |




For more information about selecting the control mode read the explanation of manual versus automatic control in 'Thermostatic Control' on page 4

Screen 3 This screen allows you to modify the thermostat parameters:
Line 3 only visible if mode = "outlet water step"

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|-------------------|----------------------|---------|-------------|-------------|------|
| 1 | THERMOST.SETTINGS | screen title | | | | |
| 2 | STEPLNGTH | Step length (°C) | 1.5 | 0.4 | 2.0 | 0.1 |
| 3 | STEPIFFERENCE | Step difference (°C) | 0.2 | 0.2 | 0.8 | 0.1 |
| 4.1 | LOADUP | Load up time (s) | 180 | 15 | 300 | 1 |
| 4.2 | DWN | Load down (s) | 20 | 15 | 300 | 1 |


Screen 4 This screen allows you to change the start up priority of the circuits in case of capacity demand:

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|-------------------|---|---------|-------------|-------------|------|
| 1 | LEAD-LAG SETTINGS | screen title | | | | |
| 2 | LEAD-LAG MODE | To select the automatic or manual lead-lag mode * | AUTO | | | -- |
| 3 | LEAD-LAG HOURS | To select the difference in operation time between the compressors (automatic mode) | 1000 | 100 | 1000 | 100 |
| 4 | EQUAL STARTUP | Startup both compressors and raise the capacity of both compressors with the same value | NO | NO | YES | -- |

 If you select NO for equal start-up the first compressor will go to 100%, and then the second Compressor will start-up and go to 100%

In case of 2 compressors:

| Possible manual setting 1 | Possible manual setting 2 |
|---------------------------|---------------------------|
| C1>C2 | C2>C1 |

 For more information about selecting the lead-lag mode read the explanation of 'Lead-lag Control' on page 9

Screen 5 This screen allows you to change the capacity limitation setting of the circuits via a digital input (remote switch or timer) or via the schedule timer:

| Line n° | Display | Description | Possible settings |
|---------|--------------------|--|-----------------------------------|
| 1 | CAP. LIM. SETTINGS | screen title | |
| 2 | MODE: | to select the capacity limitation mode | REMOTE DIG INP. SCHEDULE TIMER |
| 3 | L1CIR1 CIR2: | Limitation setting 1 | 0% (25%) |
| 4 | L2CIR1 CIR2: | Limitation setting 2 | 40% 70% 100% |

i note If the controller is set to REMOTE DIG INP. mode, than this setting has priority on the capacity limitation settings programmed in the SCHEDULE TIMER, and vice versa.

You have 4 limitation settings, where you can put a limit on the capacity of the compressor(s).

Screen 6

| Line n° | Display | Description | Possible settings |
|---------|--------------------|----------------------|--------------------|
| 1 | CAP. LIM. SETTINGS | screen title | |
| 2 | L3CIR1 CIR2: | Limitation setting 3 | 0% (25%) |
| 3 | L4CIR1 CIR2: | Limitation setting 4 | 40% 70% 100% |

For more information about the programming and use of the schedule timer, refer to screen 8 on this page.

Screen 7 This screen allows you to force the pump via the chiller controller and to adjust the pump lead and lag time.

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|--------------|---|---------|-------------|-------------|-------|
| 1 | PUMPCONTROL | 1.2.9.1.1.1 screen title | | | | |
| 2 | PUMPLEADTIME | 1.2.9.1.1.2 Time to run the water pump before starting up the chiller | 020 sec | 020 sec | 180 sec | 1 sec |
| 3 | PUMPLAGTIME | 1.2.9.1.1.3 Time to keep the pump on, after stopping the chiller | 000 sec | 000 sec | 180 sec | 1 sec |
| 4.1 | DAILY ON | 1.2.9.1.1.4 To activate a daily pump start up | N | N | Y | --- |
| 4.2 | AT | 1.2.9.1.1.5 Pump start time | 00h00 | 00h00 | 24h00 | 1 min |

i note The user will get the choice to perform a pump start every day to prevent obstruction of the pump and to increase the lifetime of the pump. Every day at pump start time, which can be set, the pump will be started automatically for a short time period (5s) when the unit is not on.

Remark: the default value for the PUMPLAGTIME is 0 sec, but it is recommend to set the lag time to 120s. This is to prevent that the evaporator freezes up when there is no flow.

Screen 8 This screen allows you to enable or disable the schedule timer and the holiday period timer. Screen visible if (MS Option = No) or (MS Option Setting = Yes and Unit = master)

| Line n° | Display | Description | Possible settings |
|---------|--------------------|--|-------------------|
| 1 | SCHEDULE TIMER | screen title | |
| 2 | ENABLE TIMER | To get the possibility to work with the programmable schedule timer | N Y |
| 3 | ENABLE HOLIDAY PER | To get the possibility to work with the programmable holiday period timer | N Y |

i note New screens will be available if one or both timer possibilities are put on Yes. When the user has selected to work with a schedule timer it will be possible to define up to four groups. Days can then be appointed to one of these groups. Each group can have up to nine different actions (time periods, capacity limitation, set points, cooling/heating selection). If Timer and Holiday Period are both set as enable then the Holiday period will get the priority.

Screen 8a1 This additional screen appears when ENABLE TIMER is set to Yes
 Screen visible if Enable timer =Yes and (MS Option = No or if (MS Option setting = Yes and Unit = Master)

| Line n° | Display | Description | Possible settings |
|---------|----------------|--|---------------------|
| 1 | SCHEDULE TIMER | screen title | |
| 2 | MON: THU: SAT: | To allocate a certain group to one of these days | -, G1, G2, G3 or G4 |
| 3 | TUE: FRI: SUN: | To allocate a certain group to one of these days | -, G1, G2, G3 or G4 |
| 4 | WED: | To allocate a certain group to this day | -, G1, G2, G3 or G4 |

For all groups mentioned in the above table up to 4 additional screens will follow.
 (Example: see screen 8b1).

Screen 8b1 This additional screen appears when ENABLE TIMER is set to Yes and if a group is allocated to a certain day.

Screen example for group 1 (G1):

| Line n° | Display | Description |
|---------|------------------|---|
| 1a | GROUP 1:01 TO 03 | To set action 1 to 3 for one of the four groups. |
| 1b | GROUP 1:04 TO 06 | To set action 4 to 6 for one of the four groups. |
| 1c | GROUP 1:07 TO 09 | To set action 7 to 9 for one of the four groups. |
| 2 | X:00h00 - 00.0 | To set one of the nine times and actions And specify a setpoint or capacity limitation. (see below for possibilities) |
| 3 | X:00h00 - 00.0 | |
| 4 | X:00h00 - 00.0 | |

Screen visible if Enable timer Yes=1 and (MS Option = No or if (MS Option setting = Yes and Unit = Master)

Possible operation time settings:

| Lower limit | Upper limit | Step | Default |
|-------------|-------------|-------|---------|
| 00h00 | 23h59 | 1 min | 00h00 |

Possible ON/OFF settings:

| Possible settings | Description |
|-------------------|-----------------------|
| - | No action |
| ON | Unit on |
| OFF | Unit off |
| ON COOL | Unit works in cooling |
| ON HEAT | Unit works in heating |

Possible SETPOINT settings:

| Possible settings | Description | Default | Lower limit | Upper limit | Step |
|-------------------|------------------------------------|---------|-------------|-------------|-------|
| ISP1(2) E | Evaporator inlet water setpoint 1 | 12.0°C | MOW +3°C | 23.0°C | 0.1°C |
| OSP1(2) E | Evaporator output water setpoint 1 | 7°C | MOW | 16°C | 0.1°C |
| ISP1 C | Condenser inlet water setpoint 1 | 23.0°C | 15.0°C | 50.0°C | 0.1°C |
| ISP2 C | Condenser inlet water setpoint 2 | 23.0°C | 15.0°C | 50.0°C | 0.1°C |

i note : the value of ISP1 E ~ ISP2 C are different from the values described into the setpoints menu.

Possible CAPACITY LIMITATION settings:

| Possible settings | Description |
|-------------------|------------------------|
| LIM1 | Capacity limitation 1 |
| LIM2 | Capacity limitation 2 |
| LIM3 | Capacity limitation 3 |
| LIM4 | Capacity limitation 4 |
| NO-LIM | No capacity limitation |

Screen 8a2

This additional screen appears when ENABLE HOLIDAY is set to Yes.
Screen visible if Enable Holiday Yes and (MS Option = No or if (MS Option setting = Yes and Unit = Master)

| Line n° | Display | Description |
|---------|--------------------|--|
| 1a | HD PERIOD:01 TO 03 | To set holiday period 1 to 3. |
| 1b | HD PERIOD:04 TO 06 | To set holiday period 4 to 6. |
| 1c | HD PERIOD:07 TO 09 | To set holiday period 7 to 9. |
| 1d | HD PERIOD:10 TO 12 | To set holiday period 10 to 12. |
| 2 | X:00/00 TO 00/00 | To set one of the twelve holiday periods |
| 3 | X:00/00 TO 00/00 | To set one of the twelve holiday periods |
| 4 | X:00/00 TO 00/00 | To set one of the twelve holiday periods |

Screen 8b2

This additional screen appears when ENABLE HOLIDAY is set to Yes.
And you choose HOLIDAY in screen 8b1(= screen with group settings).

| Line n° | Display | Description |
|---------|------------------|--|
| 1a | HOLIDAY:01 TO 03 | To select the programmed holiday period 1 to 3. |
| 1b | HOLIDAY:04 TO 06 | To select the programmed holiday period 4 to 3. |
| 1c | HOLIDAY:07 TO 09 | To select the programmed holiday period 7 to 9. |
| 2 | X:00h00 - 00.0 | To set one of the nine times and actions And specify a setpoint or capacity limitation. |
| 3 | X:00h00 - 00.0 | |
| 4 | X:00h00 - 00.0 | |



For possible operation times and action settings, see the possible settings for the schedule timer on the previous pages .

i note Only 1 group of settings is possible for all programmed holidays (max. 12).

Schedule timer example

| MARCH | | | | | | |
|-------|-------|-------|-------|-------|-------|-------|
| MON | TUE | WED | THU | FRI | SAT | SUN |
| 1 G1 | 2 G1 | 3 G2 | 4 G1 | 5 G1 | 6 G3 | 7 G3 |
| 8 G1 | 9 G1 | 10 G2 | 11 G1 | 12 G1 | 13 G3 | 14 G3 |
| 15 G1 | 16 G1 | 17 G2 | 18 G1 | 19 G1 | 20 G3 | 21 G3 |
| 22 G1 | 23 H | 24 H | 25 H | 26 H | 27 H | 28 H |
| 29 H | 30 G1 | 31 G2 | | | | |

To come to the schedule above following settings have to be made:

```

┌┐ SCHEDULE TIMER
MON: G1 THU: G1 SAT: G3
TUE: G1 FRI: G1 SUN: G3
WED: G2

```

⋮

```

┌┐ HO PERIOD: 01 TO 03
01: 23/03 TO 29/03
02: 00/00 TO 00/00
03: 00/00 TO 00/00


```

All days assigned to the same group will work according to the settings of this group.

In this example setting:

- all Mondays, Tuesdays, Thursdays and Fridays will work according to the settings in group 1 (G1),
- all Wednesdays will work according to the settings in group 2 (G2),
- all Saturdays and Sundays will work according to the settings in group 3 (G3),
- all holiday days will work according to the settings in the holiday group (H).

All group settings of groups G1, G2, G3, G4 and H work similar as following example (settings for group 1):



```

┌┐ GROUP1: 01 TO 03
1: 06:00 ISP1 E: 12.0
2: 06:00 ON
3: 08:00 ISP1 E: 14.0

```

Screen 1

⋮

```

┌┐ GROUP1: 04 TO 06
4: 12:00 OFF
6: 13:00 ON
8: 20:00 OFF

```

Screen 2

Screen 9

This screen will only be visible if in service menu (screen 20) Dual Evap. Pump is selected as digital output
Visible if DO1Cha="2ND EVAP" or DO2Cha="2ND EVAP"

| Line n° | Display | Description | Possible settings |
|---------|-----------------|---|--|
| 1 | DUAL EVAP. PUMP | screen title | |
| 2 | MODE | Select the start-up mode | AUTOM. ROTATION PUMP2 > PUMP1 PUMP1 > PUMP 2 |
| 3 | OFFSET ON RH | Running hours offset value (default value 048h) | 001h-999h |

For more information on pump control, refer to 'Pump Control' on page 11

Screen 10

This screen allows you to set the floating setpoint.
Only available on a Cooling only unit or RC unit

| Line n° | Display | Description | Possible settings |
|---------|-------------------|--------------|-----------------------|
| 1 | FLOATING SETPOINT | screen title | |
| 2 | MODE | | NOT ACTIVE AMBIENT |

Screen 10a

When you choose ambient mode the following settings will appear.

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|-------------------|--|---------|-------------|-------------|-------|
| 1 | FLOATING SETPOINT | screen title | | | | |
| 2 | MODE : | Selected mode | | | | |
| 3 | MAX VALUE : | Max value of floating setpoint correction | 3°C | 0°C | 5°C | 0.1°C |
| 4.1 | ZERO: | Here the setpoint value will be equal to 0. | 20°C | 20°C | 43°C | 0.1°C |
| 4.2 | SLOPE | This parameter is necessary to draw the angle of the curve | 5°C | 0°C | 10°C | 0.1°C |

Screen 11 This screen allows you to modify the display settings.

| Line n° | Display | Description | Possible settings |
|---------|------------------|--------------------------------|--|
| 1 | DISPLAY SETTINGS | screen title | |
| 2 | LANGUAGE | To select the desired language | ENGLISH DEUTSH FRANCAIS ESPANGNOL ITALIANO |
| 3 | TIME | To set the actual time | 00h00–23h59 |
| 4 | DATE | To set the actual date | MON-SUN 01/01/00-31/12/99 |

Screen 12

This screen will only be visible if in service menu (screen 20) Free cooling is selected as digital output
Only visible if unit type = “CO or RC”

| Line n° | Display | Description | Possible settings |
|---------|--------------|---|--|
| 1 | FREE COOLING | screen title | |
| 2 | MODE: | Choose mode to regulate the free cooling on | NOT ACTIVE INLET-AMBIENT AMBIENT |

Ambient: free cooling is based on ambient temperature

Inlet-Ambient: free cooling is based on the difference between inlet water temperature and ambient temperature

Screen 12a

When you choose (Inlet -)ambient mode the following settings will appear.

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|--------------|--|---------|-------------|-------------|-------|
| 1 | FREE COOLING | screen title | | | | |
| 2 | MODE : | Selected mode | | | | |
| 3.1 | SP: | Define setpoint of free cooling | 5°C | -30°C | 25°C | 0.1°C |
| 3.2 | DI: | Setting of the free cooling difference | 1.0°C | 1.0°C | 5.0°C | 0.1°C |
| 4.1 | PUMP: | Depends on free cooling application. See Free cooling page 29. | OFF | OFF | ON | |
| 4.2 | LEAD : | The time the pump CHWP has to run before the chiller can start up no free cooling. | 0s | 0s | 999s | 1s |

Line 4 will only be visible if Ambient is selected.

Screen 13

Additional screens if DICN is selected.

- i When used in DICN option, the Schedule Timer (screens 8...) will only be available on the master unit

Screens on the master unit.

Only visible if MS Option setting = Yes & unit = Master

| Line n° | Display | Description | Possible settings |
|---------|----------------|--|-------------------|
| 1 | MASTER SETTING | screen title | |
| 2 | NR OF SLAVES: | Enter the number of slaves you want to use on the DICN network | 0 / 1 / 2 / 3 |

Screen 13a

Only visible if MS Option setting = Yes

| Line n° | Display | Description | Possible settings |
|---------|----------------|--|--------------------------------------|
| 1 | MASTER SETTING | screen title | |
| 2 | MODE | Normal: the unit works normally. Standby: if the unit is in standby it will only start-up in case of the other DICN units has to little capacity. Disconnected: the unit is disconnected of the DICN Unit. | NORMAL DISCONN. ON/OFF STANDBY |
| 3 | OFFSET | After the adjusted hours the units will change the sequence of start-up. | 0h till 9000h |
| 4 | PUMP ON IF: | Select when the pump must start | UNIT ON COMPR ON |

Screen 13b

Screen on the slave unit :

| 1.2.9.1.1. | 1.2.9.1.1.7 Display | 1.2.9.1.1.8 Description | 1.2.9.1.1.9 Possible settings |
|------------|---------------------|--|--------------------------------------|
| 1 | SLAVE # SETTING | 1.2.9.1.1.10 screen title | SLAVE 1 / 2 / 3 |
| 2 | MODE | Normal: the unit works normally. Standby: if the unit is in standby it will only start-up in case of the other DICN units has to little capacity. Disconnected: the unit is disconnected of the DICN Unit. | NORMAL DISCONN. ON/OFF STANDBY |
| 3 | OFFSET | 1.2.9.1.1.11 After the adjusted hours the units will change the sequence of start-up. | 0h till 9000h |
| 4 | PUMP ON IF: | 1.2.9.1.1.12 Select when the pump must start. This selection is for the unit only | UNIT ON COMPR ON |

Screen 14 This screen allows you to protect the access of the setpoint menu by password.

| Line n° | Display | Description | Possible settings |
|----------------|--------------------|--|--------------------------|
| 1 | SETPOINT PASSWORD | screen title | |
| 2 | PASSWORD NEEDED TO | Depending on the setting the system may require the password to enter the setpoint menu. | No Yes |
| 3 | CHANGE SETPOINT | | |

2.9.2 Service Menu

Screen 15 You need the password to enter this menu. The unit leaves the factory with password 1914.

| Line n° | Display | Description |
|---------|----------------|----------------------------|
| 1 | ENTER SERVICE | Screen title |
| 3 | PASSWORD: 0000 | Enter the correct password |

i note when the unit is running it is not possible to enter the service menu.

Screen 16 This screen allows you to modify the minimum outlet water, the BMS communication interval and the master-slave option
Line 4 is not visible for unit type = "ER" Unit

| Line n° | Display | Description | Possible settings | Default |
|---------|------------------|--|--|---------|
| 1 | SERVICE MENU | Screen title | | |
| 2 | MIN. OUTL. WATER | To select the minimum outlet water temperature | -15°C -10°C -5°C 0°C 2°C 4°C 5°C 8°C | 4°C |
| 3 | FINETUNE(BMS) | To select the communication interval | From 0s till 60s | 30s |
| 4 | MS OPTION | To select master-slave option yes or no | Y or N | N |

Screen 17 This screen allows you to modify the low pressure bypass timer, the low pressure setpoint and delay network error.
Line 4 is only visible if MS Option setting = Yes

| Line n° | Display | Description | Possible settings | Default |
|---------|------------------|---------------------------------------|--------------------|---------|
| 1 | SERVICE MENU | Screen title | | |
| 2.1 | LP SETPOINT | Specify the low pressure limit | 0.2bar till 3.5bar | ** |
| 2.2 | PDWN | Low pressure setpoint for pumpdown. | 0.2bar till 3.5bar | 0.2bar |
| 3 | LP BYPASSTIMER | To set the low pressure bypass timer | From 0s till 180s | 120s |
| 4 | DELAY NETW. ERR. | To set the delay of the network error | From 30s till 600s | 120s |

** Default setpoint depends on refrigerant type:

1 bar for R134a

1,5 bar for R407c

Screen 18

This screen allows you to modify the compressor running hours and number of start-ups (e.g. after replacing a compressor).

| Line n° | Display | Description | Possible settings |
|---------|----------------------|--|----------------------------------|
| 1 | SERVICE MENU | Screen title | |
| 2 | RUN.HRS-COMPR STARTS | Screen title | |
| 3.1 | RH1: | Readout of actual running hours of compressor 1 | Changeable from 00000h to 99999h |
| 3.2 | CS1: | Readout of actual number of starts of compressor 1 | Changeable from 00000h to 99999h |
| 4.1 | RH2: | Readout of actual running hours of compressor 2 | Changeable from 00000h to 99999h |
| 4.2 | CS2: | Readout of actual number of starts of compressor 2 | Changeable from 00000h to 99999h |

Screen 19

This screen allows you to set the changeable digital inputs.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|----------------------------|---|
| 1 | CHANG.INP/OUTPUTS | Screen title | |
| 2 | DI1: | To set the digital input 1 | NONE DUAL SETPOINT REMOTE ON/OFF REMOTE COOL/HEAT CAP. LIMIT 1 CAP. LIMIT 2 CAP. LIMIT 3 CAP. LIMIT 4 FANSETP SHIFT |
| 3 | DI2: | To set the digital input 2 | |
| 4 | DI3: | To set the digital input 3 | |



When you want to program on of these inputs, you have to check the field wiring to see if this input is installed.

Screen 20

This screen allows you to set the changeable digital in- and output.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|----------------------------|---|
| 1 | CHANG.INP/OUTPUTS | Screen title | |
| 2 | DI4: | To set the digital input 1 | NONE DUAL SETPOINT REMOTE ON/OFF REMOTE COOL/HEAT CAP. LIMIT 1 CAP. LIMIT 2 CAP. LIMIT 3 CAP. LIMIT 4 FANSETP SHIFT |
| 3 | DO1: | To set the digital output | REV. VALVE(C/H) 2 ND EVAP PUMP CONDENSER PUMP 100% CAPACITY FREE COOLING EVAP.HEATERTAPE GEN.OPERATION |
| 4 | DO2: | | |



When you want to program one of these outputs, you have to check the field wiring and output terminals to see if it is installed.
For more info on these digital outputs refer to Digital output on page 3.

Screen 21

This screen allows you to set a changeable analogue input

| Line n° | Display | Description | Possible settings |
|---------|------------------|---|---|
| 1 | CHANG.IN/OUTPUTS | 1.2.9.2.1.1 Screen title | |
| 2 | AI3 | To set a floating setpoint with an electrical signal. | NONE SETP.SIGN.0/1V SETP.SIGN.0/10V SETP.SIGN.0/20mA SETP.SIGN.4/20mA |
| 3 | MAX SETP.DIF: | 1.2.9.2.1.2 Maximum difference between setpoints | 1.2.9.2.1.3 Between -50°C and 50°C |

See page 32 for more info on this function.

Screen 22

This screen allows you to adjust the offset of the probe.
Line 2 not visible in case of 'ER' unit type

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|----------------|--|---------|-------------|-------------|-------|
| 1 | PROBE OFFSET | Screen title | | | | |
| 2 | AI4 INLET E : | To set the accuracy of the evaporator inlet water temperature | 0.0°C | -0.5°C | 0.5°C | 0.1°C |
| 2 | AI5 OUTLET E : | To set the accuracy of the evaporator outlet water temperature | 0.0°C | -0.5°C | 0.5°C | 0.1°C |
| 3 | AI6 AMBIENT : | To set the accuracy of the ambient temperature | 0.0°C | -0.5°C | 0.5°C | 0.1°C |

Screen 23


This screen allows you to adjust the BMS settings.

| Line n° | Display | Description | Default | Possible settings |
|---------|--------------|--|----------|---------------------------------------|
| 1 | BMS SETTINGS | Screen title | | |
| 2 | SER. BOARD: | To select the communication protocol between the BMS and the gateway | NONE | NONE RS485 RS422 |
| 3 | PROTOCOL: | Indicates the communication protocol | CAREL | CAREL |
| 4 | BAUD RATE: | To select the baud rate for communication between the BMS card and the gateway (RS485) | 1200 bps | 1200 2400 4800 9600 19200 |
| | | To select the baud rate for communication between the BMS card and the gateway (RS422) | 1200 bps | 1200 2400 4800 |

Screen 24

This screen allows you to activate the PC control mode and to modify the BMS settings.

| Line n° | Display | Description | Default | Possible settings |
|---------|---------------------|--|---------|-------------------|
| 1 | BMSBOARD SETTINGS | Screen title | | |
| 2 | BMSCONTROL ALLOWED: | To allow BMS control | NO | NO /YES |
| 3 | BMS ADDRESS PCB: | Used to address circuits of the unit towards the gateway | 01 | 01 till 32 |
| 4 | ON LINE: | Indicates if there is communication between controller and computer. | NO | YES - NO |

 Refer to the BMS manual for more information

Screen 25

This screen allows you to customize the flow indication after start up.

| Line n° | Display | Description | Default | Possible settings |
|---------|--------------------------------|--|---------|-------------------|
| 1 | SERVICE MENU | Screen title | | |
| 2/3 | IF NO FLOW AFTER PUMPLEADTIME: | To select if the unit should go into alarm or standby status if there is no flow after start up. | ALARM | ALARM/STANDBY |
| 4 | MANUAL TEST PUMP: | To be able to check the operation of the pump manually. This means that when the unit is off the pump can also be turned on at any time to check the pump. | OFF | ON/OFF |

i note The pump can only be switched on manually by changing the parameter, do not enter it! When you enter on the parameter then it will automatically change to N again and the pump will be switched off. This is done in order to eliminate the possibility that the pump remains on without being checked.

Screen 26

This screen allows you to customize the freeze up safety.

| Line n° | Display | Description | Default | Possible settings |
|---------|------------------------|---|------------|--------------------------|
| 1 | SERVICE MENU | Screen title | | |
| 2 | FREEZE UP: | To select one of the freeze up settings. | DIS&SAFETY | DIS&SAFETY/ DIS. ONLY |
| 3.1 | SAFETY: | Number of allowed freeze ups during a specified time before the circuit would stop. | 4 | 1/2/3/4/5 |
| 3.2 | IN | To select the time in which a specified number of freeze ups is allowed. | 60 | 5 till 180min |
| 4 | INL CHECK AFTER RESET: | To select if the unit should check the inlet water temperature before reset. | N | Y/N |

i note **DISABLE ONLY:**
The circuit will shut off after every freeze up protection (activated from MOW-1,5K) and will reset automatically if evaporator outlet temperature = MOW. There will be no fault indication on the controller.

DISABLE & SAFETY:
The circuit will shut off after every freeze up protection (activated from MOW-1K) and give a fault indication after the number of allowed freeze ups during a specified time has expired. The safety must be reset manually.

Screen 27

This screen allows you to customize the fan safety.

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|--------------|--|---------|-------------|-------------|--------|
| 1 | SERVICE MENU | Screen title | | | | |
| 2.1 | FAN UP: | Delay timer until the fans go up after Fan HP is reached | 10s | 0s | 180s | 1s |
| 2.2 | DOWN : | Delay timer until the fans switch off after Fan LP is reached | 180s | 0s | 180s | 1s |
| 3.1 | FAN LP : | Fan lower Limit, when pressure is reached the fan down timer starts counting(R134a) | 5.5bar | 5.5bar | 8.7bar | 0.1bar |
| | FAN LP : | Fan lower Limit, when pressure is reached the fan down timer starts counting (R407c) | 10bar | 10bar | 15bar | 0.1bar |
| 3.2 | HP : | Fan higher Limit, fans start when pressure is reached(R134a) | 8bar | 8bar | 11.2bar | 0.1bar |
| | HP : | Fan higher Limit fans start when pressure is reached (R407c) | 14bar | 14bar | 19bar | 0.1bar |
| 4 | DIFF : | Fan step difference | 0.5bar | 0.5bar | 3bar | 0.1bar |
| 4.2 | SHIFT | To set fanshift | 5.0bar | 0 | ** | 0.1bar |

** Maximum fanshift = HPSETB – HP – 0.5 bar.
 HPSETB can be found on next screen.

Screen 28

Line 4 only visible if MS Option setting = Yes

| Line n° | Display | Description | Default | Lower limit | Upper limit | Step |
|---------|--------------|---|---------|-------------|-------------|--------|
| 1 | SERVICE MENU | Screen title | | | | |
| 2.1 | C12%: | Set the timer to run in 12% mode | 20s | 20s | 180s | 1s |
| 2.2 | START: | Timer to set the compressor to the first capacity step | 20s | 20s | 360s | 1s |
| 3.1 | STOP: | Timer to set to 12% before stop. | 8s | 0s | 99s | 1s |
| 3.2a | HP SETBACK : | (R134a) fan control to assure a minimum high pressure when the ambient temperature is low | 15.5bar | 15.5 bar | 17 bar | 0.1bar |
| 3.2b | HP SETBACK : | (R407c) fan control to assure a minimum high pressure when the ambient temperature is low | 24.5bar | 23.5 bar | 26 bar | 0.1bar |
| 4.1 | MS PR : | Unit priority –stepL Priority | 0-2 | 0-0 | 3-4 | 1-1 |
| 4.2 | AI3: | Accuracy of analogue input 3 | 0°C | -0.5°C | +0.5°C | 0.1°C |

When the high pressure rises above the high pressure setback value the unit will be limited on 70% maximum and the fans will all work for as long as the high pressure setback timer (200s) is counting down.

When unit is stopped the compressor is forced to 12% before it is shut down. This is done to avoid start-ups at 100%.

i *Unity priority – stepL Priority*

The first digit of the Master Slave Priority refers to the Unit priority. With this digit you can give each unit a certain start up priority.

The second digit refers to the Step Length priority. This setting reacts only on load up steps and avoids that one of the DICN units goes into freeze-up alarm because the common leaving water is still to high. (See page 27)

Screen 29

This screen allows you to choose whether a password is needed to reset safeties.

| Line n° | Display | Description | Possible settings |
|---------|--------------------|--|---|
| 1 | SERVICE MENU | Screen title | |
| 2 | PASSWORD NEEDED TO | | |
| 3 | RESET SAFETIES: | | |
| 4 | | Indication of the password needed to reset safeties. | NONE USER PASSWORD SERVICE PASSWORD |

Screen 30 This screen allows you to adjust the EEV settings
Only visible if EEV1 or EEV2 is present

| Line n° | Display | Description | Possible settings |
|---------|------------------|--|-------------------|
| 1 | EEV SERVICE MENU | Screen title | |
| 2 | SCREENS : | Enabling additional screens (see screen 7 Readout menu) EEV readout | N or Y |
| 2.1 | BATTERY : | Enable battery (if present) | N or Y |
| 3 | POWER ON,NO SAF: | Set delay timer before safety will be displayed (default 90s) | 10 – 120 s |

Screen 31a This screen allows you to adjust the EEV settings
Only visible if EEV1 or EEV2 is present

| Line n° | Display | Description |
|---------|------------------|---------------------------|
| 1 | EEV DRIVER C1(2) | Screen title |
| 3 | NO WARNINGS | No warnings on EEV driver |

Screen 31b This screen allows you to see and reset the warning
Only visible if EEV1 or EEV2 is present

| Line n° | Display | Description | Possible settings |
|---------|---------------------|--------------|-------------------|
| 1 | EEV DRIVER C1(2) | Screen title | |
| 2 | SYSTEM WAITING FOR: | | |
| 3 | VALVE OPEN | | |
| 4 | GO AHEAD: | | N - Y |

After setting GO AHEAD on Y you will be able to reset the Valve Open error on the Error menu

Screen 31c This screen allows you to see if the battery is charged
Only visible if EEV1 or EEV2 is present

| Line n° | Display | Description | Possible settings |
|---------|------------------|---------------------------------|-------------------|
| 1 | EEV DRIVER C1(2) | Screen title | |
| 3 | BATTERY CHARGED | Indicates if battery is charged | |
| 4 | | Status | N – Y |

2.10 Timers Menu

Software timers Using this menu you can read the actual value of the software timers. This menu displays four screens.

Screen 1 This screen shows the actual value of the general timers:
Line 2 not visible if unit is a “ER” unit

| Line n° | Display | Description |
|---------|----------------|--|
| 1 | GENERAL TIMERS | Screen title |
| 2a.1 | LOADUP: | Delay timer for loading up; during countdown, the unit is unable to enter a higher thermostat step (default 180s) |
| 2a.2 | -DWN: | Delay timer for loading down; during countdown, the unit is unable to enter a lower thermostat step (default 20s) |
| 3a | PUMPLEAD: | The time the pump has to run before the chiller can start up. |
| 3b | PUMPLAG: | The time the pump still has to run after stopping the chiller. (appears when PUMPLEAD TIME =0) |
| 3c | PUMPDAILY: | Countdown timer, counts if the daily pump start is activated and if the start time is reached. (See PUMPCONTROL page.11) |
| 4 | FLOWSTOP: | Delay timer that starts counting when the water flow through the evaporator stops during normal operation; if the water flow has not started during the countdown, the unit will shut down (default: 5s) |

Screen 2 This screen shows the actual value of the startup difference timer:

| Line n° | Display | Description |
|---------|--------------------------|---|
| 1 | COMPRESSOR TIMERS | Screen title |
| 2 | COMPR. STARTED | Startup difference timer (5s). If more than one compressor starts up at the same time than there has to be 5 seconds between startups. |
| 3a | | |
| 3b | CIRCUIT PI RUNTIME: | |
| 4a | | |
| 4b | 1: s- 2: s | Timers for circuit 1 and circuit 2 |

Screen 3

This screen shows the actual value of the compressor timers:

| Line n° | Display | Description |
|---------|-------------------|--|
| 1 | COMPRESSOR TIMERS | Screen title |
| 2 | GRD1: s AREC1: s | Guard timer & Anti recycling timer for compressor of circuit 1 |
| 3 | GRD2: s AREC2: s | Guard timer & Anti recycling timer for compressor of circuit 2 |

i note Guard timer: delay timer to prevent compressor from restarting after a shutdown (default 60s).


Anti recycling timer: AREC timer is used to limit the starts per hour, means counting after starting the compressor. Screw compressor = 600sec (6 starts/hour)

Screen 4

This screen shows the actual value of the compressor timers:

| Line n° | Display | Description |
|---------|-------------------|--|
| 1 | COMPRESSOR TIMERS | Screen title |
| 2.1 | START1: | Delay timer to limit compressor capacity to 40% (25% if present) during the countdown (default: 140s) |
| 2.2 | STOP: | |
| 3.1 | START2: | Delay timer to limit compressor capacity to 40% (25% if present) during the countdown (default: 140s) |
| 3.2 | STOP | |

The following view shows an example of the working of the timers



The startup time depends on the setting of the timer of the 40% step (or 25% step if present).
 The startup time is 20s + the time of the first step. Default 140s

2.11 Safety & History Menu

Safety Information The Safeties Menu appears when a unit/circuit/network/dual pump safety is activated. The kind of safety will be displayed with a code, followed by its description.

The access to the safeties menu can be restricted with a password.

The safety menu is linked to the history screen. By pushing the enter key you jump to the history menu where, along with the basic information, more detailed data screens can be consulted, by pressing the ↵ key.

Screen layout

| Line n° | Display | Descripti on |
|---------|---|--|
| 1a | UNIT SAFETY CIRCUIT SEFETY NETWORK SAFETY DUAL PUMP SAFETY | Indicates if you have a unit, pump or network safety. (Not possible to reset, safety is still present) |
| 1b | RESET UNIT SAFETY RESET C1 SAFETY RESET C2 SAFETY RESET NETW SAFETY RESET D PUMP SAFETY | After solving the problem, the alarm key starts blinking and the display indicates that resetting is possible. (possible to reset) |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |

History information The History menu contains all the information concerning the latest shutdowns. The structure of those menus is identical to the structure of the safety menu. Whenever a failure is solved and the operator performs a reset, the concerning data from the safety menu is copied into the history menu. The user will be able to go back and check up to 20 occurred faults. Warnings are also recorded.

Additionally the number of safeties that already occurred can be consulted on the first line of the history screens.

Screen overview Press the ζ key to get the status of the complete unit at the time of the safety.

Screen 1

| Line n° | Display | Description |
|---------|--|---|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates the safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3 | XXhXX – XX/XX/XX | Indicates time and date of safety. |
| 4 | INLSETP1 E: XXX°C or INLSETP2 E: XXX°C or OUTSETP1 E: XXX°C or OUTSETP2 E: XXX°C or INLSETP1 C: XXX°C or INLSETP2 C: XXX°C or SP1E: C: or SP2E: C: or THERMOSTAT or MANUAL MODE | Indicates the mode and set point at the moment of shutdown. |

You can go from one sub-screen to another and from a screen to a sub-screen using the \downarrow key.

i note The sub-screens automatically disappear after 5 seconds.

Screen 1.1 Push the \downarrow key to enter the first sub-screen.

| Line n° | Display | Description |
|---------|--|--|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates if it was a unit, circ 1, circ2, network or pump safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3 | INL.E: XXX°C | Actual measured evaporator inlet temperature at the moment of shutdown. |
| 4 | OUT.E: XXX°C | Actual measured evaporator outlet temperature at the moment of shutdown. |

Screen 1.2 Push the ↵ key to enter the second sub-screen.

| Line n° | Display | Description |
|---------|--|--|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates if it was a unit, circ 1, circ2, network or pump safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3a | OUTC1: XXX°C | Actual measured evaporator outlet temperature of circuit 1 at the moment of shutdown. |
| 3b | STEP: | Indicates capacity step at the moment of shutdown. |
| 4 | OUTC2: XXX°C | Actual measured evaporator outlet temperature of circuit 2 at the moment of shutdown. |

Screen 1.3 Push the ↵ key to enter the third sub-screen.

| Line n° | Display | Description |
|---------|--|--|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates if it was a unit, circ 1, circ2, network or pump safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3 | C1: | Actual status of the compressor of circuit 1 at the moment of shutdown. |
| 4 | C2: | Actual status of the compressor of circuit 2 at the moment of shutdown. |

Screen 1.4 Push the ↵ key to enter the fourth sub-screen.

| Line n° | Display | Description |
|---------|--|--|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates if it was a unit, circ 1, circ2, network or pump safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3 | HP1: = °C | Actual status of the high pressure of circuit 1 at the moment of shutdown. |
| 4 | LP1: = °C | Actual status of the low pressure of circuit 1 at the moment of shutdown. |

Screen 1.5 Push the ↵ key to enter the fifth sub-screen.

| Line n° | Display | Description |
|---------|--|--|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates if it was a unit, circ 1, circ2, network or pump safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3 | HP2: = °C | Actual status of the high pressure of circuit 2 at the moment of shutdown. |
| 4 | LP2: = °C | Actual status of the low pressure of circuit 2 at the moment of shutdown. |

Screen 1.6 Push the ↵ key to enter the sixth sub-screen.

| Line n° | Display | Description |
|---------|--|--|
| 1 | UNIT HISTORY:XXX CIRC 1 HISTORY:XXX CIRC 2 HISTORY:XXX NET HISTORY:XXX PUMP HISTORY :XXX EEV1 HISTORY :XXX EEV2 HISTORY :XXX | Indicates if it was a unit, circ 1, circ2, network or pump safety. XXX is the serial number of the alarm. |
| 2 | XXX:XXXXXXXXXXXX | Indicates the safety code and its description. |
| 3 | RH 1: | Actual running hours of the compressor of circuit 1 at the moment of shutdown. |
| 3a | AMB.T | Actual ambient temperature at the moment of shutdown. |
| 4 | RH 2: | Actual running hours of the compressor of circuit 2 at the moment of shutdown. |

2.12 Info Menu

Additional unit information

Using this menu you can consult additional information about the unit. There are four screens.

Screen 1

This screen shows you the actual time and date.

| Line n° | Display | Description |
|---------|-------------------|--------------------|
| 1 | TIME INFORMATION | Screen title |
| 2 | TIME: XXhXX | Actual time |
| 3 | DATE:XXX XX/XX/XX | Actual day en date |



Refer to the “User Settings & Service Menu” to adjust the correct time, day and date. See screen 11 on page 56.

Screen 2

This screen shows you the unit type.

| Line n° | Display | Description |
|---------|-------------------------------|---|
| 1 | UNIT INFORMATION | Screen title |
| 2 | UNITTYPE: AW-CO-XX | Unit type (40, 50, 60, 80, 100, 120, 140, 160, 180, 200) |
| 3 | CIRC: EVAP: | Indicates the quantity of circuits and Evaporators |
| 3 | REFRIGERANT : XXXX | Refrigerant type (R407C / R134a) |

i unit type explanation : WW : Water water cooled
 AW : Air water cooled

 CO : cooling only
 HP : Heatpump
 HR: Heat recovery
 RC : Remote condenser
 CA : ER

Screen 3

This screen shows you the used software version.
Line 4 only visible if EEV1 = Yes or EEV2 = Yes

| Line n° | Display | Description |
|---------------|------------------|---|
| 1 | UNIT INFORMATION | Screen title |
| 2 | SW: | Indicates the software version and date. |
| 3 | SW CODE: | Indicates the software code. |
| 4 EEV1: -2: | XXXXXX | The hardware (first 3 digits) and software version (last 3 digits) of the EEV driver |

Screen 4

This screen shows you PCB information.

| Line n° | Display | Description |
|----------------|-----------------|--|
| 1 | PCB INFORMATION | Screen title |
| 2 | BOOT: | Indicates boot version and date. |
| 3 | BIOS: | Indicates bios version and date. |
| 4 | pLAN ADDRESS : | Gives the address that is set on the dipswitch (For DICN) |

2.13 Input/Output Status Menu

Reading the status of inputs and outputs

Using this menu you can read the status of the digital inputs and the status of the relay outputs.

- Screen 1 to 7 provides the status of the digital inputs.
- Screen 8 to 16 provides the status of the relay outputs.

Screen 1

This screen shows you the status of the emergency stop and the flowswitch.

| Line n° | Display | Description | Possible settings |
|---------|-----------------|--------------------------|-------------------|
| 1 | DIGITAL INPUTS | Screen title | |
| 2 | EMERGENCY STOP: | Status of emergency stop | OK/NOK |
| 3 | FLOWSWITCH: | Status of flow switch | FLOW OK/NO FLOW |

- i* A Unit safety can be a high or low pressure safety, a discharge thermal protector safety or an over current safety.

Screen 2

This screen shows you the status of digital inputs of circuit 1.

| Line n° | Display | Description | Possible settings |
|---------|------------------|--|-------------------|
| 1 | DIGITAL INPUTS | Screen title | |
| 2 | C1 HIGH PR. SW. | Status of high pressure switch of circuit 1 | OK/NOK |
| 3 | C1 REV.PH.PROT.: | Status of reverse phase protector of circuit 1 | OK/NOK |
| 4 | C1 OVERCURRENT | Status of overcurrent switch of circuit 1 | OK/NOK |

Screen 3

This screen shows you the status of digital inputs of circuit 1.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|--|-------------------|
| 1 | DIGITAL INPUTS | Screen title | |
| 2 | C1 DISCH. TH. PR. | Status of discharge temperature protection switch of circuit 1 | OK/NOK |
| 3 | C1 COMPR. TH. PR. | Status of compressor temperature protection of circuit 1 | OK/NOK |

Screen 4

This screen shows you the status of digital inputs of circuit 2.

| Line n° | Display | Description | Possible settings |
|---------|------------------|--|-------------------|
| 1 | DIGITAL INPUTS | Screen title | |
| 2 | C2 HIGH PR. SW. | Status of high pressure switch of circuit 2 | OK/NOK |
| 3 | C2 REV.PH.PROT.: | Status of reverse phase protector of circuit 2 | OK/NOK |
| 4 | C2 OVERCURRENT | Status of overcurrent switch of circuit 2 | OK/NOK |

Screen 5

This screen shows you the status of the digital inputs of circuit 2.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|--|-------------------|
| 1 | DIGITAL INPUTS | Screen title | |
| 2 | C2 DISCH. TH. PR. | Status of discharge thermal protection switch of circuit 2 | OK/NOK |
| 3 | C2 COMPR. TH. PR. | Status of compressor thermal protection of circuit 2 | OK/NOK |

Screen 6

This screen shows you the status of the digital inputs.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|--|-------------------|
| 1 | DIGITAL INPUTS | Screen title | |
| 2 | THERMOSTAT STATUS | | |
| 2 | 25% : 40% : | Indicates at which capacity step the unit is operating | N-Y |
| 3 | 70% : 100% : | | N-Y |

Screen 7

This screen shows you the status of the flow switch and the reverse phase protector.

| Line n° | Display | Description | Possible settings | Possible status |
|---------|--------------------|--|---|---|
| 1 | CHANG. DIG. INPUTS | Screen title | | |
| 2 | DI1 XXXX:XXX | Changeable digital input 1 + status of input | NONE DUAL SETPOINT REMOTE ON/OFF REMOTE COOL/HEAT CAP. LIMIT 1 CAP. LIMIT 2 CAP. LIMIT 3 CAP. LIMIT 4 FANSETP.SHIFT | SETP.1/SETP.2 ON/OFF COOL/HEAT NO LIM/LIMIT NO LIM/LIMIT NO LIM/LIMIT NO LIM/LIMIT N/Y |
| 3 | DI2 XXXX:XXX | Changeable digital input 2 + status of input | | |
| 4 | DI3 XXXX:XXX | Changeable digital input 3 + status of input | | |

Screen 8

This screen shows you the status of the compressor relays of circuit 1.

| Line n° | Display | Description | Possible settings |
|---------|------------------|---|-------------------|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | CIRCUIT 1 ON: | Indicates the status of the compressor | NO/YES |
| 3 | CIRCUIT 1 STAR: | Indicates if the compressor is in star | NO/YES |
| 4 | CIRCUIT 1 DELTA: | Indicates if the compressor is in delta | NO/YES |

Screen 9

This screen shows you the status of the compressor relays of circuit 2.

| Line n° | Display | Description | Possible settings |
|---------|------------------|---|-------------------|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | CIRCUIT 2 ON: | Indicates the status of the compressor | NO/YES |
| 3 | CIRCUIT 2 STAR: | Indicates if the compressor is in star | NO/YES |
| 4 | CIRCUIT 2 DELTA: | Indicates if the compressor is in delta | NO/YES |

Screen 10

This screen shows you the status of the relay outputs of the compressor.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|---|-------------------|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | C1(12%): C1(25%): | Indicates the status of the compressor of circuit 1 | Y or N |
| 3 | C1(40%): C1(70%): | Indicates the status of the compressor of circuit 1 | Y or N |

Screen 11

This screen shows you the status of the relay outputs of the compressor.

| Line n° | Display | Description | Possible settings |
|---------|-------------------|---|-------------------|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | C2(12%): C2(25%): | Indicates the status of the compressor of circuit 2 | Y or N |
| 3 | C2(40%): C2(70%): | Indicates the status of the compressor of circuit 2 | Y or N |

Screen 12

This screen shows you the status of the relay outputs of the fans from circuit 1.
Only for Aircooled

| Line n° | Display | Description | Possible settings |
|---------|---------------|--|-------------------|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | C1 FANSTEP 1 | Indicates the status of the fan contactor of circuit 1 | Open / closed |
| 3 | C1 FANSTEP 2 | Indicates the status of the fan contactor of circuit 1 | Open / closed |
| 4 | C1 FANSTEP 3 | Indicates the status of the fan contactor of circuit 1 | Open / closed |

Screen 13

This screen shows you the status of the relay outputs of the fans from circuit 2.
Only for Aircooled

| Line n° | Display | Description | Possible settings |
|---------|---------------|--|-------------------|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | C2 FANSTEP 1 | Indicates the status of the fan contactor of circuit 2 | Open / closed |
| 3 | C2 FANSTEP 2 | Indicates the status of the fan contactor of circuit 2 | Open / closed |
| 4 | C2 FANSTEP 3 | Indicates the status of the fan contactor of circuit 2 | Open / closed |

Screen 14

This screen shows you the status of the general alarm and the pump contacts.

| Line n° | Display | Description | Possible settings |
|---------|----------------|---|--|
| 1 | RELAY OUTPUTS | Screen title | |
| 2 | GEN. ALARM: | Indicates the status of the general alarm contact | OPEN/CLOSED |
| 3 | PUMP/GEN OPER: | Indicates the status of the pump contact | OPEN/CLOSED |
| 4 | AI3: | Indicates the type of signal on analogue input 3 | NONE SETP.SIGN. mV SETP.SIGN. V SETP.SIGN. mA |

Screen 15

This screen shows you the status of the changeable digital output.
If unit type = ER then disable line 2

| Line n° | Display | Description | Possible settings | Possible status |
|---------|-----------------------|---|---|--|
| 1 | CHANG. INP/OUTPUTS | Screen title | | |
| 2 | DI4 XXXX:XXXX | Changeable digital input 4 + status of input | NONE DUAL SETPOINT REMOTE ON/OFF REMOTE COOL/HEAT CAP. LIMIT 1 CAP. LIMIT 2 CAP. LIMIT 3 CAP. LIMIT 4 | SETP.1/SETP.2 ON/OFF COOL/HEAT NO LIM/LIMIT NO LIM/LIMIT NO LIM/LIMIT NO LIM/LIMIT |
| 3 | DO1 XXXXXXXX | Changeable digital output 1 + status of output | 2 ND EVAP PUMP EVAP.HEATERTAPE GEN.OPERATION FREE COOLING 100% CAPACITY REV.VALVE COND PUMP | O/C (Open/Closed) |
| 4 | DO2 XXXXXXXX | Changeable digital output 1 + status of output | 2 ND EVAP PUMP EVAP.HEATERTAPE GEN.OPERATION FREE COOLING 100% CAPACITY REV.VALVE COND PUMP | O/C (Open/Closed) |

Screen 16

This screen shows you to see the status of the In/Outputs of the EEV
Only if EEV SCREEN = Yes and EEV1(2) = Yes

| Line n° | Display | Description | Possible settings |
|---------|---------------------|---------------------------|--|
| 1 | EEV1 (2) IN/OUTPUTS | Screen title | |
| 2 | BATTERY: | Status of the battery | DISCONNECTED HIGH INT.RES NOT RECHARGE |
| 3 | VALVE POSITION | The position of the valve | 0 - 9999 |

2.14 User password Menu

Password The password protects the access to:

- | the user settings menu
- | the set points menu

The password is a 4-digit number between 0000 and 9999.

The units leave the factory with use password 0000. The service password is 1914 this password overrides the user password(in case you don't know it or forgot it).

Screen 1 In this screen you have to set the current password to change it to another one.

| Line n° | Display | Description | Possible settings |
|---------|----------------|-----------------------------|---------------------|
| 1 | ENTER PASSWORD | Screen title | |
| 3 | PASSWORD: 0000 | To set the current password | From 0000 till 9999 |

Screen 2 In this screen you can change the password.

| Line n° | Display | Description | Possible settings |
|---------|----------------|-----------------------------|---------------------|
| 1 | ENTER PASSWORD | Screen title | |
| 2 | NEW PASSWORD: | To set the new password | From 0000 till 9999 |
| 3 | CONFIRM: | To confirm the new password | From 0000 till 9999 |

2.15 Cool/Heat Menu

Screen 1 This screen allows you to choose between cooling and heating.

| Line n° | Display | Description | Possible settings |
|---------|-----------------|-----------------------------------|---|
| 1 | COOLING/HEATING | Screen title | |
| 3 | MODE: | To select cooling or heating mode | COOLING (EVAP) HEATING (COND) DOUBLE THERM. |

i Cool/Heat Menu is only available on water cooled chillers

The cooling or heating mode can be selected via a changeable digital input (see 'Service Menu' screen 19, page 60) or directly via the controller display.

2.16 Network Menu

Network menu is only accessible when MS OPTION (service menu) is yes

Screen 1 Line2, 3, 4 only visible if MSOption = Yes

| Line n° | Display | Description | Possible settings |
|---------|--------------|--|--|
| 1 | NETWORK | | |
| 2 | XXXXXXX | Gives the setpoint you selected to use (usersettings menu and dual setpoint if selected) | MANUAL MODE INLSETP1(2) E OUTSETP1(2) E INLETSP1(2) C SP1(2) E: C: THERMOSTAT |
| 3 | INL WATER E | Inlet temperature of the inlet water on the master unit. | °C |
| 4 | OUTL WATER E | Gives the temperature of the outlet water of all units together | °C |

Line 4 is only visible if in usersettings menu the control setting mode is “OUTL WATER STEP”.

An extra temperature sensor (optional) measures the temperature of the water of all units together. This is not the outlet water temperature of a unit but the temperature of outletwater of all units (installation is field supplied)

Screen 2


| Line n° | Display | Description | Possible settings |
|---------|---------|---|--------------------------------------|
| 1.1 | M : | Displays status of Master (as selected in usersettings menu) | NORMAL / STANDBY DISCONN / SAFETY |
| 1.2 | ST : | Displays the Step of the master | |
| 2.1 | SL1: | Displays status of the slave (as selected in usersettings menu) | NORMAL / STANDBY DISCONN / SAFETY |
| 2.2 | ST : | Displays the Thermostat Step of the slave | |
| 3.1 | SL2: | Displays status of the slave (as selected in usersettings menu) | NORMAL / STANDBY DISCONN / SAFETY |
| 3.2 | ST : | Displays the Thermostat Step of the slave | |
| 4.1 | SL3: | Displays status of the slave (as selected in usersettings menu) | NORMAL / STANDBY DISCONN / SAFETY |
| 4.2 | ST : | Displays the Thermostat Step of the slave | |

2.17 To adjust the contrast of the display

| Built-in display | Remote terminal |
|---|-----------------|
| <ol style="list-style-type: none">1. Press 1st Enter Key and hold2. Press 2nd OnOff Key and hold3. Keep the two buttons pressed, and use the Up and Down Key to adjust the contrast | Not possible |

When you use a pCO controller as a remote controller on a pCO² it is possible that you don't see anything on the pCO controller.

On the upper left corner of the back of the pCO controller you will find a hole. There you can adjust the brightness of the pCO controller with a small screw driver.



2.18 To enter the pumpdown menu

| Built-in display | Remote terminal |
|--|--|
| <ol style="list-style-type: none"> Go to the second screen of the userpassword menu (“change password”) Press Enter Key and Menu Key at the same time and hold them for 5 seconds. | <ol style="list-style-type: none"> In Password2 display Press Enter Key and Menu Key at the same time and hold them for 5 seconds. |

To execute a pumpdown follow instructions on screens.

Screen 1

| Line n° | Display | Description | Possible settings |
|---------|--------------------|--|-------------------|
| 1 | CIRCUIT 1(2) : | Displays circuit to pump down. (Select between C1 or C2) | PUMPDOWN |
| 2 | CLOSE LIQUIDE LINE | | |
| 3 | STOPVALVE | | |
| 4 | (ENTER WHEN READY) | | |

Screen 2

| Line n° | Display | Description | Possible settings |
|---------|------------------|-------------|-------------------|
| 1 | _PUMPDOWN | | |
| 2 | PUT UNIT ‘ON’ TO | | |
| 3 | START PUMPDOWN | | |
| 4 | PROCEDURE | | |

Screen 3

| Line n° | Display | Description | Possible settings |
|---------|----------------------|---|-------------------|
| 1 | _PUMPDOWN BUSY | Number indicate the number of start-up cycles of the compressor | 1 2 3 |
| 2 | CLOSE THE DISCHARGE | | |
| 3 | STOPV.IF PUMPDOWN IS | | |
| 4 | FINISHED LP: | Displays the low pressure | bar |

The compressor will execute 3 pumpdown cycles. See upper line in controller screen 'PUMPDOWN BUSY123' (compressor stops at LP<0.2bar and starts again at LP>0.2bar)

Screen 4

| Line n° | Display | Description | Possible settings |
|----------------|---------------------|--------------------|--------------------------|
| 1 | _PUMPDOWN FINISHED | | |
| 2 | PRESS ENTER TO STOP | | |
| 3 | PUMPDOWN | | |
| 4 | | | |

Part 2 Troubleshooting

Introduction When a problem occurs, you have to check all possible faults. This chapter gives a general idea of where to look for faults. Furthermore the general procedures for refrigeration circuit repair and for electrical circuit repair are explained.

i Not all repair procedures are described. Some procedures are considered common practice.




What is in this part? This part contains the following chapters:

| Topic | See page |
|--|----------|
| Overview of Fault Indications and Safeties | 87 |
| 1 – Unit and circuit errors | 89 |
| 2 – EEV Errors | 91 |

Overview of Fault Indications and Safeties.







In the first stage of trouble shooting sequence it is important to interpret the fault indication on the controller display. This will help you to find the cause of the problem.

What happens in the event of an alarm The units are equipped with three kinds of safety devices.

| | Unit alarm | Circuit alarm | Dual Pump alarm |
|------------------------|--|---|--|
| Function | Protects the unit in general | Protects the individual circuit | Indicates dual evaporator pump status |
| Description | <ul style="list-style-type: none"> ‡ All compressors are shut down. ‡ The red LED inside the key lights up | <ul style="list-style-type: none"> ‡ The compressor of the corresponding circuit is shut down. ‡ The red LED inside the key lights up | <ul style="list-style-type: none"> ‡ Malfunction of one of the two evaporator pumps |
| Action to take | Press  to acknowledge the alarm | Press  to acknowledge the alarm | Press  to acknowledge the alarm |
| Display example | OAE:FLOW HAS STOPPED OU1:REVERSE PHASE PR | 1CA:OUT E SENSOR ERR 1EO:GENERAL SAFETY 1A4:FREEZE –UP PROT. | OAE:FLOW HAS STOPPED |

What to do in the event of an alarm

In event of an alarm or a warning, the following happens:

| Step | Action | Result |
|------|--|--|
| 1 | Press  to acknowledge the alarm. | <ul style="list-style-type: none"> ‡ The  LED lights up ‡ An unit, circuit, network, or dual pump safety is displayed. |
| 2 | Find the cause of the alarm and correct it. | The system is repaired. |
| 3 | You have found the cause and correct it | The  LED start blinking. Now it is possible to reset |
| 3 | Press  to reset the alarm. | <ul style="list-style-type: none"> ‡ The  LED goes out and the alarm screen is deactivated. ‡ The main menu screen is displayed automatically. <p><u>Remark:</u> if in the service menu the option “password needed to reset safeties” is activated, you will be asked to enter the correct password to reset the safety.</p> <p><i>i</i> After resetting the alarm you can consult the safety information only using the history menu on page 68</p> |
| 4 | If all circuits were shutdown , switch on the unit by pressing  . | The units starts again. |

1. Unit and Circuit Errors

Overview of codes The following alarm and warning codes may appear on the screen:

Safety devices

| Safety indication | Activation | Reset |
|----------------------|--|---|
| Dual pump Safety | Malfunction of one of the two evaporator pumps | Manual software reset |
| Network safety | Malfunction or disconnected network | Manual software reset |
| Circuit 1 (2) safety | Indicates that there is a safety in the indicated circuit. | You can only reset when the problem on that circuit is solved |
| Unit safety | Unit safety, unit is switching off | Manual software reset |

Alarm devices

| Alarm description | Alarm indication | Activation | Reset | Wiring code | Device |
|-----------------------------|-------------------------|--|---|--------------------------|-----------------------------|
| Emergency stop | 0F0: EMERGENCY STOP | When emergency stop button is pushed. | Manual software reset. After reset of the emergency stop switch. | | |
| Flow switch or pump contact | 0AE:FLOW HAS STOPPED | No flow after 5 seconds | Manual software reset | S8L (field supply) | Contact closed on flow |
| Outlet evaporator error | 0CA: OUT E SENSOR ERR | <ul style="list-style-type: none"> • Out of range • Broken / disconnected | Manual software reset | | NTC sensor |
| Inlet evaporator error | 0C9: INL E SENSOR ERR | <ul style="list-style-type: none"> • Out of range • Broken / disconnected | Manual software reset | R3T | NTC sensor |
| PCB communication error | 0U4: PCB COMM.PROBLEM | Network isn't OK <ul style="list-style-type: none"> ▪ Check cable (wrong / disconnected.) ▪ Check dip switch address | Manual software reset | | PCO ² controller |
| Outlet evaporator error | 1/2CA: OUT E SENSOR ERR | <ul style="list-style-type: none"> • Out of range • Broken / disconnected | Manual software reset | R4T R6T (Cir 1 Cir 2) | NTC sensor |

| | | | | | |
|---------------------------------|------------------------------------|--|--|----------------------------|----------------|
| Low pressure transmitter error | 1/2JC: LP TRANSM ERR | <ul style="list-style-type: none"> The transferred value of the transmitter is out of range Transmitter gives no signal (broken) | Manual software reset | B1P B4P (Cir 1 Cir 2) | LP Transmitter |
| High pressure transmitter error | 1/2JA: HP TRANSM ERR | <ul style="list-style-type: none"> The transferred value of the transmitter is out of range Transmitter gives no signal (broken) | Manual software reset | B2P B5P (Cir 1 Cir 2) | HP Transmitter |
| Low pressure error | 1/2E4: LOW PRESSURE | Low Pressure is <0.2 Bar (Programmable) | Manual software reset | B1P B4P (Cir 1 Cir 2) | LP Transmitter |
| Discharge thermal protection | 1/2F3: DISCH THERM PROT | High compressor discharge temperature >135°C | Manual software reset if temperature <115°C | S3T S4T (Cir 1 Cir 2) | Bimetal on/off |
| Overcurrent | 1/2E6: OVERCURRENT | overcurrent | Manual software reset and if overcurrent relay is in manual mode manual reset on relay in switch box | K17S K18S (Cir 1 Cir 2) | Bimetal on off |
| High pressure switch | 1/2E3: HIGH PRESSURE SW | High pressure is > 26 bar (R407c) High pressure is > 17 bar (R134a) | Manual software reset | S1PH S2PH (Cir 1 Cir 2) | HP switch |
| Reverse phase protection | 1/2U1: REV PHASE PROT | <ul style="list-style-type: none"> Single phasing Imbalance of more than 20% between the phases Reversed phases No power | Correct phase sequence, switch power back on | R1P R2P (Cir 1 Cir 2) | Contact on/off |
| Freeze-up | 1/2A4: FREEZE UP 0A4: FREEZE UP | Number of allowed freeze-up in a period is reached (see 1.5 freeze up control on page 7) | Manual reset only if temperature is raised with 1.5K | | NTC sensor |
| Inlet condenser error | 0HC: INL C SENSOR ERR | <ul style="list-style-type: none"> Out of range Broken / disconnected | Manual software reset | | NTC sensor |
| Ambient temperature error | 0H9: AMB T SENSOR ERR | <ul style="list-style-type: none"> Out of range Broken / disconnected | Manual software reset | R5T | NTC sensor |

Remark:

- 1 or 2 in the fault code gives an indication of the circuit
0 in the fault code gives an indication of the Unit
- The overcurrent relay can be set to manual or automatic reset. When the relay is set to manual reset, the overcurrent relay must be reset in the switch box. After reset, only alarm button is flashing. The controller can now be reset.

2. EEV Driver Error list

| For units with EEV drivers | | | | | | | | | | | | | | | | |
|--|---------|--------------------------------|--|---|---|---|---|---|--|--|--|--|---|--|---|--|
| A) present for units with 1 EEV driver | | pCO2 controller | | | | | | | | | | | | | | |
| B) present for units with 2 EEV drivers | | | | | | | | | | | | | | | | |
| (start) only if error is present during power on | | | | | | | | | | | | | | | | |
| (or) pLAN LED can be on or flashing | | Display | | | | | | | | | | | | | | |
| Cause | Symptom | | | | | | | | | | | | | | | |
| | | Alarm menu No error message | Alarm menu CIRCUIT1/2 SAFETY 1/2E4: LOW PRESSURE | Alarm menu CIRCUIT1/2 SAFETY 1/2A9:EEV DRIVER ERR | Alarm menu CIRCUIT1/2 SAFETY 1/2A9:EEV NOT CLOSED | Alarm menu CIRCUIT1/2 SAFETY 1/2A9:EEV SUPERHEAT ER | Alarm menu CIRCUIT1/2 SAFETY 1/2A9:EEV EEPROM ERR | Alarm menu CIRCUIT1/2 SAFETY 1/2A9:EEV ST.MOTOR ERR | Alarm menu CIRCUIT1/2 SAFETY 1/2A9:EEV PROBE ERR | Alarm menu EEV1/2 SAFETY 1/2A9:EEV BATTERY ERR | Alarm menu NETWORK SAFETY DU4: PCB COMM. PROBLEM | READOUTMENU ACT. PRESSURES C1/2 LP1/2: 00.0 b=-36.2 °C | READOUTMENU ACT. PRESSURES C1/2 LP1/2: -2.06 b=-ER °C | INFO MENU UNIT INFORMATION EEV1/2:000000 | SERVICE MENU EEV1/2 DRIVER(03/04) NO WARNINGS | SERVICE MENU EEV1/2 DRIVER(03/04) SYSTEM WAITING FOR: VALVE OPEN GO AHEAD:NO |
| 1) EEV driver circuit 1/2 has no power | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 2) pLAN (tx-/tx+) is not connected | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 3) pLAN (tx-/tx+) of this EEV driver is reversed connected | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 4) pLAN (tx-/tx+) of another EEV driver is reversed connected | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 5) pLAN address setting of driver is equal to address setting of pCO2 controller (ex PCO2=1 & EEV1=1) | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 6) pLAN address setting of driver is not correct and different from pCO2 controller (ex PCO2=1 & EEV1=4) | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 7) pLAN address setting of drivers are equal and diff from pCO2 controller (ex PCO2=1 & EEV1=3 & EEV2=3) | | (start) | x | | | | | | (start) | x | (start) | | (start) | x | | (start) |
| 8) pLAN VG0(24V) EEV-driver is disconnected | | | | | | | | | | | | | | | | |
| 9) pLAN VG1(24V) EEV-driver is disconnected | | (start) | x | | | | | | | x | x | x | | x | x | x |
| 10) EEV pressure probe not connected | | | | | | | | | x | | | | x | | | |
| 11) EEV pressure probe broken | | | | | | | | | x | | | | | | | |
| 12) EEV NTC sensor not connected | | | | | | | | | x | | | | | | | |
| 13) EEV NTC sensor broken | | | | | | | | | x | | | | | | | |
| 14) EEV Eprom is broken | | | | | | | | x | | | | | | | | |
| 15) EEV superheat to low | | | | | | | x | | | | | | | | | |
| 16) Valve did not close during stop (for example during power off) | | (start) | | x | | | | | | | | x | | | | x |
| 17) EEV driver is new (has never been used before) | | (start) | | x | | | | | | | | x | | | | x |
| 18) EEV battery disconnected | | | | | | | | | | x | | | | | | |

